N NEXPEAK K1   SUZUKI Function list V16.10

Notes	
√	Functions marked with √ is fully supported and already exited in former software version.
	Functions left with blank is not supported.

Vehicle	Mode	ECU information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
	ENG	√	√	√	√		Misc Test
	AT/CVT	√	√	√	√		
	ABS/ESP	√	√	√	√		
	EPS	√	√	√	√		
	SRS	√	√	√	√		
	AC	√	√	√	√		
	BCM	√	√	√	√		Misc Test
	4WD	√	√	√	√		
	EMCD	√	√	√			
	EV_MOTOR	√	√	√			