

N NEXPEAK K1 **Key program Function List V10.10**

#	Brand	System	Fuction
1	Lutos	Siemens anti theft system	1. Password setting 1.1. Set password 1.2. Input password 2. Programming function 2.1. Key matching 2.2. Key earase 2.3. ECU matching of burglar alarm 2.4. Engine ECU matching 2.5. Program the VIN of the burglar alarm 2.6. Program engine Vin 2.7. Reset the engine ECU 2.8. Immobilizer ECU reset 2.9. New system matching
2	Lutos	Original anti-theft system	1. Key matching 2. Key removal
3	Lutos	Power on anti-theft system	Programming function 1. Key matching 2. Key removal 3. ECU matching of burglar alarm 4. Engine ECU matching 5. Program the VIN of the burglar alarm 6. Program engine Vin 7. Reset the engine ECU 8. Immobilizer ECU reset 9. New system matching 10. Read VIN code 11. Key detection 12. Lock the burglar alarm 13. Engine ECU detection