

**NEXPEAK K1****OPEL Function list V17.12**

Note:

√ Functions marked with √ is fully supported and already existed in former software

Number Index number of the special function , you can find the name from the special function table.

Functions is not supported.

Vehicle	System	ECU Info.	Read Code	Clear Code	Live Data
OPEL\2017\Adam	Engine Control Module\1.2L (LWD)	√	√	√	√
OPEL\2017\Adam	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2017\Adam	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Adam	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2017\Adam	Transmission Control Module	√	√	√	√
OPEL\2017\Adam	Fuel Injector Control Module	√	√	√	√
OPEL\2017\Adam	Chassis Control Module	√	√	√	√
OPEL\2017\Adam	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Adam	Body Control Module	√	√	√	√
OPEL\2017\Adam	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Adam	Instrument Cluster	√	√	√	√
OPEL\2017\Adam	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Adam	Radio\Radio (UH7)	√	√	√	√
OPEL\2017\Adam	Radio\Radio (UM7)	√	√	√	√
OPEL\2017\Adam	Radio\Radio (IOA)	√	√	√	√
OPEL\2017\Adam	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Adam	HVAC Control Module	√	√	√	√
OPEL\2017\Adam	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2017\Adam	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2017\Ampera-e	Engine Control Module		√	√	√
OPEL\2017\Antara	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2017\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2017\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2017\Antara	Power Steering Control Module	√	√	√	√
OPEL\2017\Antara	Body Control Module	√	√	√	√
OPEL\2017\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2017\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2017\Antara	Headlamp Control Module	√	√	√	√
OPEL\2017\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2017\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2017\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2017\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2017\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2017\Antara	Radio\None	√	√	√	√
OPEL\2017\Antara	HVAC Control Module	√	√	√	
OPEL\2017\Antara	Remote Control Door Lock Receiver\Not Equipped	√	√	√	√
OPEL\2017\Antara	Remote Control Door Lock Receiver\Tire Pressure Monitoring System - Manual Learn (UJM)	√	√	√	√
OPEL\2017\Antara	Parking Assist Control Module	√	√	√	√

OPEL\2017\Astra-J	Engine Control Module\Not Equipped\1.4L (LUJ)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Not Equipped\1.6L (LDE)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Not Equipped\1.6L (LWC)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Not Equipped\1.6L (LVL)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Not Equipped\1.6L (LVM)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.4L (LUJ)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LDE)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LWC)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LVL)	√	√	√	√
OPEL\2017\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LVM)	√	√	√	√
OPEL\2017\Astra-J	Transmission Control Module	√	√	√	√
OPEL\2017\Astra-J	Fuel Injector Control Module	√			√
OPEL\2017\Astra-J	Chassis Control Module	√	√	√	√
OPEL\2017\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2017\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2017\Astra-J	Body Control Module	√	√	√	√
OPEL\2017\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2017\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2017\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2017\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Astra-J	Radio\Chime (UL5)	√	√	√	
OPEL\2017\Astra-J	Radio\Radio	√	√	√	√
OPEL\2017\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2017\Astra-J	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2017\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2017\Astra-J	Frontview Camera Module	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.4L (LV7)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.4L (LE2)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.6L (LWV)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.6L (LWQ)	√	√	√	√
OPEL\2017\Astra-K	Engine Control Module\1.6L (LVK)	√	√	√	√
OPEL\2017\Astra-K	Transmission Control Module\Automatic\Automatic Transmission T-76	√	√	√	√
OPEL\2017\Astra-K	Transmission Control Module\Automatic\Manual Transmission Automatically Shifted	√	√	√	√
OPEL\2017\Astra-K	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Astra-K	Power Steering Control Module	√	√	√	√
OPEL\2017\Astra-K	Body Control Module	√	√	√	√
OPEL\2017\Astra-K	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Astra-K	Instrument Cluster	√	√	√	√
OPEL\2017\Astra-K	Radio Controls	√	√	√	√
OPEL\2017\Astra-K	Headlamp Control Module	√	√	√	√
OPEL\2017\Astra-K	Trailer Interface Control Module	√	√	√	√

OPEL\2017\Astra-K	Radio\Radio (IOB)	√	√	√	√
OPEL\2017\Astra-K	Radio\Radio (IP1)	√	√	√	√
OPEL\2017\Astra-K	Radio\Chime (UL5)	√	√	√	
OPEL\2017\Astra-K	Radio\Uplevel (IO4 IO5 IO6)	√	√	√	√
OPEL\2017\Astra-K	Human Machine Interface Control Module	√	√	√	√
OPEL\2017\Astra-K	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Astra-K	HVAC Control Module	√	√	√	√
OPEL\2017\Astra-K	Seat Memory Control Module	√	√	√	√
OPEL\2017\Astra-K	Keyless Entry Control Module	√	√	√	√
OPEL\2017\Astra-K	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2017\Astra-K	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2017\Astra-K	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2017\Astra-K	Frontview Camera Module	√	√	√	√
OPEL\2017\Astra-K	Steering Column Lock Control Module	√	√	√	√
OPEL\2017\Astra-K	Serial Data Gateway Module	√	√	√	√
OPEL\2017\Astra-K	HVAC Controls	√	√	√	√
OPEL\2017\Astra-K	Liftgate Control Module	√	√	√	√
OPEL\2017\Astra-K	Long Range Radar Sensor Module	√	√	√	√
OPEL\2017\Cascada	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Cascada	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2017\Cascada	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2017\Cascada	Transmission Control Module	√	√	√	√
OPEL\2017\Cascada	Chassis Control Module	√	√	√	√
OPEL\2017\Cascada	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Cascada	Parking Brake Control Module	√	√	√	√
OPEL\2017\Cascada	Power Steering Control Module	√	√	√	√
OPEL\2017\Cascada	Body Control Module	√	√	√	√
OPEL\2017\Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Cascada	Instrument Cluster	√	√	√	√
OPEL\2017\Cascada	Headlamp Control Module	√	√	√	√
OPEL\2017\Cascada	Radio\Radio	√	√	√	√
OPEL\2017\Cascada	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2017\Cascada	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Cascada	HVAC Control Module	√	√	√	√
OPEL\2017\Cascada	Front Seat Heating Control Module	√	√	√	√
OPEL\2017\Cascada	Parking Assist Control Module	√	√	√	√
OPEL\2017\Cascada	Frontview Camera Module	√	√	√	√
OPEL\2017\Cascada	Folding Top Control Module	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.6L (LJ5)\Euro 5B (NCM)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.6L (LJ5)\Euro 6 (NTA)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2017\Combo-D	Engine Control Module\1.4L (LUS)	√	√	√	√
OPEL\2017\Combo-D	Transmission Control Module	√	√	√	√
OPEL\2017\Combo-D	Electronic Brake Control Module\Vehicle Stability System (FX3)	√	√	√	√

OPEL\2017\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2017\Combo-D	Body Control Module	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.2L (LDC)	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.3L (LKV)	√	√	√	√
OPEL\2017\Corsa-E	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2017\Corsa-E	Transmission Control Module\Automatic\Automatic Transmission T-76	√	√	√	√
OPEL\2017\Corsa-E	Transmission Control Module\Automatic\Manual Transmission Automatically Shifted	√	√	√	√
OPEL\2017\Corsa-E	Fuel Injector Control Module	√	√	√	√
OPEL\2017\Corsa-E	Chassis Control Module	√	√	√	√
OPEL\2017\Corsa-E	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Corsa-E	Body Control Module	√	√	√	√
OPEL\2017\Corsa-E	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Corsa-E	Instrument Cluster	√	√	√	√
OPEL\2017\Corsa-E	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Corsa-E	Radio\Radio (IOA)	√	√	√	√
OPEL\2017\Corsa-E	Radio\Radio (UH7)	√	√	√	√
OPEL\2017\Corsa-E	Radio\Radio (UM7)	√	√	√	√
OPEL\2017\Corsa-E	Radio\Chime (UL5)	√	√	√	
OPEL\2017\Corsa-E	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Corsa-E	HVAC Control Module	√	√	√	√
OPEL\2017\Corsa-E	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2017\Corsa-E	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2017\Corsa-E	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2017\Corsa-E	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2017\Corsa-E	Frontview Camera Module	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2017\Insignia	Engine Control Module\2.0L (LTG)	√	√	√	√
OPEL\2017\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T43 (M7U M7W)	√	√	√	√
OPEL\2017\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNP MNR)	√	√	√	√
OPEL\2017\Insignia	Fuel Injector Control Module	√			√
OPEL\2017\Insignia	Chassis Control Module	√	√	√	√
OPEL\2017\Insignia	Rear Differential Clutch Control Module	√	√	√	√

OPEL\2017\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2017\Insignia	Power Steering Control Module	√	√	√	√
OPEL\2017\Insignia	Body Control Module	√	√	√	√
OPEL\2017\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Insignia	Instrument Cluster	√	√	√	√
OPEL\2017\Insignia	Radio Controls	√	√	√	√
OPEL\2017\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2017\Insignia	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Insignia	Radio	√	√	√	√
OPEL\2017\Insignia	Amplifier	√	√	√	√
OPEL\2017\Insignia	Human Machine Interface Control Module	√	√	√	√
OPEL\2017\Insignia	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Insignia	HVAC Control Module	√	√	√	√
OPEL\2017\Insignia	Keyless Entry Control Module	√	√	√	√
OPEL\2017\Insignia	Left Side Object Detection Control Module	√	√	√	
OPEL\2017\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2017\Insignia	Frontview Camera Module	√	√	√	√
OPEL\2017\Insignia	Steering Column Lock Control Module	√	√	√	√
OPEL\2017\Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√
OPEL\2017\Insignia	HVAC Controls	√	√	√	√
OPEL\2017\Insignia	Liftgate Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Engine Control Module\1.0L (L5Q)	√	√	√	√
OPEL\2017\Karl - Viva	Engine Control Module\1.0L (LWT)	√	√	√	√
OPEL\2017\Karl - Viva	Transmission Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Fuel Injector Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Power Steering Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Body Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Karl - Viva	Instrument Cluster	√	√	√	√
OPEL\2017\Karl - Viva	Radio\Radio (IOB)	√	√	√	√
OPEL\2017\Karl - Viva	Radio\Radio (IP0)	√	√	√	√
OPEL\2017\Karl - Viva	Radio\Radio (IP1)	√	√	√	√
OPEL\2017\Karl - Viva	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Karl - Viva	HVAC Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Parking Assist Control Module	√	√	√	√
OPEL\2017\Karl - Viva	Frontview Camera Module	√	√	√	√
OPEL\2017\Karl - Viva	HVAC Controls	√	√	√	√
OPEL\2017\Karl - Viva	Serial Data Gateway Module	√	√	√	√
OPEL\2017\Meriva-B	Engine Control Module\1.6L (LWQ)	√	√	√	√
OPEL\2017\Meriva-B	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2017\Meriva-B	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2017\Meriva-B	Engine Control Module\1.4L (LUH)	√	√	√	√
OPEL\2017\Meriva-B	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Meriva-B	Fuel Injector Control Module	√			√
OPEL\2017\Meriva-B	Body Control Module	√	√	√	√
OPEL\2017\Meriva-B	Instrument Cluster	√	√	√	√
OPEL\2017\Meriva-B	Headlamp Control Module	√	√	√	√
OPEL\2017\Meriva-B	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Meriva-B	HVAC Control Module\Auto Control Dual Zone (CJ2)	√	√	√	√
OPEL\2017\Meriva-B	HVAC Control Module\Manual Control Single Zone (C67)	√	√	√	√
OPEL\2017\Meriva-B	HVAC Control Module\Manual Control Heater Only (C42)	√	√	√	√

OPEL\2017\Meriva-B	Parking Assist Control Module	√	√	√	√
OPEL\2017\Mokka	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Mokka	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2017\Mokka	Engine Control Module\1.8L (2H0)\2WD - Front	√	√	√	√
OPEL\2017\Mokka	Engine Control Module\1.8L (2H0)\AWD (F46)	√	√	√	√
OPEL\2017\Mokka	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2017\Mokka	Transmission Control Module	√	√	√	√
OPEL\2017\Mokka	Fuel Injector Control Module	√			√
OPEL\2017\Mokka	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2017\Mokka	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Mokka	Power Steering Control Module	√	√	√	√
OPEL\2017\Mokka	Body Control Module	√	√	√	√
OPEL\2017\Mokka	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Mokka	Instrument Cluster	√	√	√	√
OPEL\2017\Mokka	Radio Controls	√	√	√	√
OPEL\2017\Mokka	Headlamp Control Module	√	√	√	√
OPEL\2017\Mokka	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Mokka	Radio\Radio (IOA)	√	√	√	√
OPEL\2017\Mokka	Radio\Radio (IO6)	√	√	√	√
OPEL\2017\Mokka	Radio\Radio (IP1)	√	√	√	√
OPEL\2017\Mokka	Amplifier	√	√	√	√
OPEL\2017\Mokka	Human Machine Interface Control Module	√	√	√	√
OPEL\2017\Mokka	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Mokka	HVAC Control Module	√	√	√	√
OPEL\2017\Mokka	Front Seat Heating Control Module	√	√	√	√
OPEL\2017\Mokka	Keyless Entry Control Module	√	√	√	√
OPEL\2017\Mokka	Frontview Camera Module	√	√	√	√
OPEL\2017\Mokka	HVAC Controls	√	√	√	√
OPEL\2017\Movano-B	Engine Control Module\2.3L (L0C)	√	√	√	√
OPEL\2017\Movano-B	Engine Control Module\2.3L (L0D)\Euro 5B (NCM)	√	√	√	√
OPEL\2017\Movano-B	Transmission Control Module\Front Wheel Drive (FWD)	√	√	√	√
OPEL\2017\Movano-B	Transmission Control Module\Rear Wheel Drive (RWL)	√	√	√	√
OPEL\2017\Movano-B	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Movano-B	Body Control Module	√	√	√	√
OPEL\2017\Movano-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2017\Movano-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Movano-B	Instrument Cluster	√	√	√	√
OPEL\2017\Movano-B	Radio\R15 BT USB (UF7)	√	√	√	√
OPEL\2017\Movano-B	Radio\CD16 BT USB (2L7)	√	√	√	√
OPEL\2017\Movano-B	Radio\CD16 BT USB DAB (2L6)	√	√	√	√
OPEL\2017\Movano-B	Radio\Navi 50 MediaNav (200)	√	√	√	√
OPEL\2017\Movano-B	Radio\Navi 50 MediaNav DAB (100)	√	√	√	√
OPEL\2017\Movano-B	Radio\Navi 80 IntelliLink (UFZ)	√	√	√	√
OPEL\2017\Movano-B	Radio\Navi 80 IntelliLink (2L3)	√	√	√	√
OPEL\2017\Movano-B	HVAC Control Module\Manual Control Single Zone (C60)	√	√	√	√
OPEL\2017\Movano-B	HVAC Control Module\Auto Control Single Zone (C61)	√	√	√	√
OPEL\2017\Movano-B	Parking Assist Control Module	√	√	√	√
OPEL\2017\Movano-B	Frontview Camera Module	√	√	√	√
OPEL\2017\Movano-B	Serial Data Gateway Module	√	√	√	√
OPEL\2017\Movano-B	Info Display Module	√	√	√	√
OPEL\2017\Movano-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2017\Movano-B	Tire Pressure Indicator Module	√	√	√	√
OPEL\2017\Vivaro-B	Body Control Module	√	√	√	√

OPEL\2017\Vivaro-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Vivaro-B	Instrument Cluster	√	√	√	√
OPEL\2017\Vivaro-B	HVAC Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Keyless Entry Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Parking Assist Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Auxiliary Heater Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Parking Heater Control Module	√	√	√	√
OPEL\2017\Vivaro-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2017\Zafira-C	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2017\Zafira-C	Engine Control Module\1.6L (LGE)	√	√	√	√
OPEL\2017\Zafira-C	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2017\Zafira-C	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2017\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2017\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNP MNR)	√	√	√	√
OPEL\2017\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2017\Zafira-C	Chassis Control Module	√	√	√	√
OPEL\2017\Zafira-C	Electronic Brake Control Module	√	√	√	√
OPEL\2017\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2017\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2017\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2017\Zafira-C	Body Control Module	√	√	√	√
OPEL\2017\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2017\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2017\Zafira-C	Headlamp Control Module	√	√	√	√
OPEL\2017\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2017\Zafira-C	Radio\Radio (IOA)	√	√	√	√
OPEL\2017\Zafira-C	Radio\Radio (UHR)	√	√	√	√
OPEL\2017\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2017\Zafira-C	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2017\Zafira-C	HVAC Control Module	√	√	√	√
OPEL\2017\Zafira-C	Front Seat Heating Control Module	√	√	√	√
OPEL\2017\Zafira-C	Parking Assist Control Module	√	√	√	√
OPEL\2017\Zafira-C	Frontview Camera Module	√	√	√	√
OPEL\2016\Adam	Engine Control Module\Not Equipped\1.2L (LWD)	√	√	√	√
OPEL\2016\Adam	Engine Control Module\Not Equipped\1.4L (LUJ)	√	√	√	√
OPEL\2016\Adam	Engine Control Module\Not Equipped\1.0L (LE1)	√	√	√	√
OPEL\2016\Adam	Engine Control Module\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Adam	Transmission Control Module	√	√	√	√
OPEL\2016\Adam	Fuel Injector Control Module	√	√	√	√
OPEL\2016\Adam	Chassis Control Module	√	√	√	√
OPEL\2016\Adam	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Adam	Body Control Module	√	√	√	√
OPEL\2016\Adam	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Adam	Instrument Cluster	√	√	√	√
OPEL\2016\Adam	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Adam	Radio\Radio (UF7)	√	√	√	√
OPEL\2016\Adam	Radio\Radio (UH7)	√	√	√	√

OPEL\2016\Adam	Radio\Radio (UM7)	√	√	√	√
OPEL\2016\Adam	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Adam	HVAC Control Module	√	√	√	√
OPEL\2016\Adam	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2016\Adam	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2016\Adam	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2016\Adam	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2016\Antara	Transmission Control Module	√	√	√	√
OPEL\2016\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2016\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2016\Antara	Power Steering Control Module	√	√	√	√
OPEL\2016\Antara	Body Control Module	√	√	√	√
OPEL\2016\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2016\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Antara	Instrument Cluster	√	√	√	√
OPEL\2016\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2016\Antara	Headlamp Control Module	√	√	√	√
OPEL\2016\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2016\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2016\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2016\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2016\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2016\Antara	Radio\None	√	√	√	√
OPEL\2016\Antara	HVAC Control Module	√	√	√	
OPEL\2016\Antara	Remote Control Door Lock Receiver\Not Equipped	√	√	√	√
OPEL\2016\Antara	Remote Control Door Lock Receiver\Tire Pressure Monitoring System - Manual Learn (UJM)	√	√	√	√
OPEL\2016\Antara	Parking Assist Control Module	√	√	√	√
OPEL\2016\Antara	Mobile Telephone Control Module	√	√	√	
OPEL\2016\Astra-J	Engine Control Module\1.6L (LVM)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.6L (LDE)\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.6L (LDE)\Not Equipped	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2016\Astra-J	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2016\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√

OPEL\2016\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNP MNR)	√	√	√	√
OPEL\2016\Astra-J	Fuel Injector Control Module	√			√
OPEL\2016\Astra-J	Chassis Control Module	√	√	√	√
OPEL\2016\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2016\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2016\Astra-J	Body Control Module	√	√	√	√
OPEL\2016\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2016\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2016\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2016\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Astra-J	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Astra-J	Radio\Radio	√	√	√	√
OPEL\2016\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2016\Astra-J	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Astra-J	HVAC Control Module	√	√	√	√
OPEL\2016\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2016\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2016\Astra-J	Frontview Camera Module	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.4L (LE2)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.6L (LWQ)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.4L (LV7)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.6L (LWV)	√	√	√	√
OPEL\2016\Astra-K	Engine Control Module\1.6L (LVK)	√	√	√	√
OPEL\2016\Astra-K	Transmission Control Module\Automatic Transmission T-76	√	√	√	√
OPEL\2016\Astra-K	Transmission Control Module\Manual Transmission Automaticall	√	√	√	√
OPEL\2016\Astra-K	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Astra-K	Power Steering Control Module	√	√	√	√
OPEL\2016\Astra-K	Body Control Module	√	√	√	√
OPEL\2016\Astra-K	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Astra-K	Instrument Cluster	√	√	√	√
OPEL\2016\Astra-K	Headlamp Control Module	√	√	√	√
OPEL\2016\Astra-K	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Astra-K	Radio\Radio (IOB)	√	√	√	√
OPEL\2016\Astra-K	Radio\Radio (IP1)	√	√	√	√
OPEL\2016\Astra-K	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Astra-K	Radio\Uplevel (IO4 IO5 IO6)	√	√	√	√
OPEL\2016\Astra-K	Human Machine Interface Control Module	√	√	√	√
OPEL\2016\Astra-K	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Astra-K	HVAC Control Module	√	√	√	√
OPEL\2016\Astra-K	Seat Memory Control Module	√	√	√	√
OPEL\2016\Astra-K	Keyless Entry Control Module	√	√	√	√
OPEL\2016\Astra-K	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2016\Astra-K	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√

OPEL\2016\Astra-K	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2016\Astra-K	Frontview Camera Module	√	√	√	√
OPEL\2016\Astra-K	Steering Column Lock Control Module	√	√	√	√
OPEL\2016\Astra-K	Liftgate Control Module\Hands-Free Liftgate (TC2)	√	√	√	√
OPEL\2016\Astra-K	HVAC Controls	√	√	√	√
OPEL\2016\Astra-K	Power Supply Transformer	√	√	√	√
OPEL\2016\Cascada	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Cascada	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2016\Cascada	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2016\Cascada	Transmission Control Module	√	√	√	√
OPEL\2016\Cascada	Chassis Control Module	√	√	√	√
OPEL\2016\Cascada	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Cascada	Parking Brake Control Module	√	√	√	√
OPEL\2016\Cascada	Power Steering Control Module	√	√	√	√
OPEL\2016\Cascada	Body Control Module	√	√	√	√
OPEL\2016\Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Cascada	Instrument Cluster	√	√	√	√
OPEL\2016\Cascada	Headlamp Control Module	√	√	√	√
OPEL\2016\Cascada	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Cascada	Radio\Radio	√	√	√	√
OPEL\2016\Cascada	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2016\Cascada	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Cascada	HVAC Control Module	√	√	√	√
OPEL\2016\Cascada	Front Seat Heating Control Module	√	√	√	√
OPEL\2016\Cascada	Frontview Camera Module	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.4L (LUS)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.6L (LJ5)\Euro 5B (NCM)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\1.6L (LJ5)\Euro 6 (NTA)	√	√	√	√
OPEL\2016\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2016\Combo-D	Transmission Control Module	√	√	√	√
OPEL\2016\Combo-D	Electronic Brake Control Module\Vehicle Stability System (FX3)	√	√	√	√
OPEL\2016\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2016\Combo-D	Body Control Module	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.3L (LKV)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.3L (LKU)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.2L (LDC)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2016\Corsa-E	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2016\Corsa-E	Transmission Control Module\Automatic\Automatic Transmission T-76	√	√	√	√
OPEL\2016\Corsa-E	Transmission Control Module\Automatic\Manual Transmission Automatically Shifted	√	√	√	√
OPEL\2016\Corsa-E	Fuel Injector Control Module	√	√	√	√
OPEL\2016\Corsa-E	Chassis Control Module	√	√	√	√
OPEL\2016\Corsa-E	Electronic Brake Control Module	√	√	√	√

OPEL\2016\Corsa-E	Body Control Module	√	√	√	√
OPEL\2016\Corsa-E	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Corsa-E	Instrument Cluster	√	√	√	√
OPEL\2016\Corsa-E	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Corsa-E	Radio\Radio (UF7)	√	√	√	√
OPEL\2016\Corsa-E	Radio\Radio (UH7)	√	√	√	√
OPEL\2016\Corsa-E	Radio\Radio (UM7)	√	√	√	√
OPEL\2016\Corsa-E	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Corsa-E	Radio\Radio (IOA)	√	√	√	√
OPEL\2016\Corsa-E	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Corsa-E	HVAC Control Module	√	√	√	√
OPEL\2016\Corsa-E	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2016\Corsa-E	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2016\Corsa-E	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2016\Corsa-E	Frontview Camera Module	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\2.0L (LTG)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2016\Insignia	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2016\Insignia	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2016\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T43 (M7U M7W)	√	√	√	√
OPEL\2016\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNP MNR)	√	√	√	√
OPEL\2016\Insignia	Fuel Injector Control Module	√			√
OPEL\2016\Insignia	Chassis Control Module	√	√	√	√
OPEL\2016\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2016\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2016\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2016\Insignia	Power Steering Control Module	√	√	√	√
OPEL\2016\Insignia	Body Control Module	√	√	√	√
OPEL\2016\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Insignia	Instrument Cluster	√	√	√	√
OPEL\2016\Insignia	Radio Controls	√	√	√	√
OPEL\2016\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2016\Insignia	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Insignia	Radio	√	√	√	√
OPEL\2016\Insignia	Amplifier	√	√	√	√
OPEL\2016\Insignia	Human Machine Interface Control Module	√	√	√	√

OPEL\2016\Insignia	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Insignia	HVAC Control Module	√	√	√	√
OPEL\2016\Insignia	Keyless Entry Control Module\Standard Range Passive Entry (ATS)	√	√	√	√
OPEL\2016\Insignia	Left Side Object Detection Control Module	√	√	√	
OPEL\2016\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2016\Insignia	Frontview Camera Module	√	√	√	√
OPEL\2016\Insignia	Steering Column Lock Control Module	√	√	√	√
OPEL\2016\Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√
OPEL\2016\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2016\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2016\Karl - Viva	Engine Control Module\1.0L (L5Q)	√	√	√	√
OPEL\2016\Karl - Viva	Engine Control Module\1.0L (LWT)	√	√	√	√
OPEL\2016\Karl - Viva	Transmission Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Fuel Injector Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Power Steering Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Body Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Karl - Viva	Instrument Cluster	√	√	√	√
OPEL\2016\Karl - Viva	Radio\Radio (IOB)	√	√	√	√
OPEL\2016\Karl - Viva	Radio\Radio (IP0)	√	√	√	√
OPEL\2016\Karl - Viva	Radio\Radio (IP1)	√	√	√	√
OPEL\2016\Karl - Viva	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Karl - Viva	HVAC Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Parking Assist Control Module	√	√	√	√
OPEL\2016\Karl - Viva	Frontview Camera Module	√	√	√	√
OPEL\2016\Karl - Viva	HVAC Controls	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.6L (LWQ)	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.6L (LVM)	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LUH)\Not Equipped	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LUH)\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LUJ)\Not Equipped	√	√	√	√
OPEL\2016\Meriva-B	Engine Control Module\1.4L (LUJ)\Stop/Start System (KL9)	√	√	√	√
OPEL\2016\Meriva-B	Transmission Control Module	√	√	√	√
OPEL\2016\Meriva-B	Fuel Injector Control Module	√			√
OPEL\2016\Meriva-B	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Meriva-B	Parking Brake Control Module	√	√	√	√
OPEL\2016\Meriva-B	Power Steering Control Module	√	√	√	√
OPEL\2016\Meriva-B	Body Control Module	√	√	√	√
OPEL\2016\Meriva-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Meriva-B	Instrument Cluster	√	√	√	√
OPEL\2016\Meriva-B	Headlamp Control Module	√	√	√	√
OPEL\2016\Meriva-B	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Meriva-B	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Meriva-B	Digital Radio Receiver Control Module	√	√	√	√

OPEL\2016\Meriva-B	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Meriva-B	HVAC Control Module\Auto Control Dual Zone (CJ2)	√	√	√	√
OPEL\2016\Meriva-B	HVAC Control Module\Manual Control Single Zone (C67)	√	√	√	√
OPEL\2016\Meriva-B	HVAC Control Module\Manual Control Heater Only (C42)	√	√	√	√
OPEL\2016\Meriva-B	Front Seat Heating Control Module	√	√	√	√
OPEL\2016\Meriva-B	Parking Assist Control Module	√	√	√	√
OPEL\2016\Meriva-B	Mobile Telephone Control Module	√	√	√	√
OPEL\2016\Mokka	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2016\Mokka	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Mokka	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2016\Mokka	Engine Control Module\1.8L (2H0)\2WD - Front	√	√	√	√
OPEL\2016\Mokka	Engine Control Module\1.8L (2H0)\AWD (F46)	√	√	√	√
OPEL\2016\Mokka	Transmission Control Module	√	√	√	√
OPEL\2016\Mokka	Fuel Injector Control Module	√			√
OPEL\2016\Mokka	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2016\Mokka	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Mokka	Power Steering Control Module	√	√	√	√
OPEL\2016\Mokka	Body Control Module	√	√	√	√
OPEL\2016\Mokka	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Mokka	Instrument Cluster	√	√	√	√
OPEL\2016\Mokka	Headlamp Control Module	√	√	√	√
OPEL\2016\Mokka	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Mokka	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Mokka	Radio\Radio	√	√	√	√
OPEL\2016\Mokka	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2016\Mokka	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Mokka	HVAC Control Module	√	√	√	√
OPEL\2016\Mokka	Front Seat Heating Control Module	√	√	√	√
OPEL\2016\Mokka	Parking Assist Control Module	√	√	√	√
OPEL\2016\Mokka	Frontview Camera Module	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (L0D)\Euro 5B (NCM)	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (L0B)	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (L0C)	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (LWJ)	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (LWL)	√	√	√	√
OPEL\2016\Movano-B	Engine Control Module\2.3L (L2U)	√	√	√	√
OPEL\2016\Movano-B	Transmission Control Module\Front Wheel Drive (FWD)	√	√	√	√
OPEL\2016\Movano-B	Transmission Control Module\Rear Wheel Drive (RWL)	√	√	√	√
OPEL\2016\Movano-B	Body Control Module	√	√	√	√
OPEL\2016\Movano-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2016\Movano-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Movano-B	Instrument Cluster	√	√	√	√
OPEL\2016\Movano-B	Radio\R15 BT USB (UF7)	√	√	√	√
OPEL\2016\Movano-B	Radio\CD16 BT USB (2L7)	√	√	√	√
OPEL\2016\Movano-B	Radio\CD16 BT USB DAB (2L6)	√	√	√	√
OPEL\2016\Movano-B	Radio\Navi 50 MediaNav (200)	√	√	√	√
OPEL\2016\Movano-B	Radio\Navi 50 MediaNav DAB (100)	√	√	√	√
OPEL\2016\Movano-B	HVAC Control Module\Auto Control Single Zone (C61)	√	√	√	√
OPEL\2016\Movano-B	HVAC Control Module\Manual Control Single Zone (C60)	√	√	√	√
OPEL\2016\Movano-B	Parking Assist Control Module	√	√	√	√

OPEL\2016\Movano-B	Frontview Camera Module	√	√	√	√
OPEL\2016\Movano-B	Serial Data Gateway Module	√	√	√	√
OPEL\2016\Movano-B	Tire Pressure Indicator Module	√	√	√	√
OPEL\2016\Movano-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2016\Vivaro-B	Engine Control Module\Euro 4 (NT4)	√	√	√	√
OPEL\2016\Vivaro-B	Engine Control Module\Euro 5 (NCJ)	√	√	√	√
OPEL\2016\Vivaro-B	Body Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Vivaro-B	Instrument Cluster	√	√	√	√
OPEL\2016\Vivaro-B	Radio\R16 BT USB (2L4)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\CD18 BT USB (2L0)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\R16 BT USB DAB (2L1)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\CD18 BT USB DAB (2L2)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\Navi 50 (UN1)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\Navi 50 MediaNav (200)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\Navi 50 MediaNav DAB (100)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\Navi 80 IntelliLink (2L3)	√	√	√	√
OPEL\2016\Vivaro-B	Radio\Navi 80 IntelliLink (2L5)	√	√	√	√
OPEL\2016\Vivaro-B	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Vivaro-B	HVAC Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Keyless Entry Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Parking Assist Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Auxiliary Heater Control Module	√	√	√	√
OPEL\2016\Vivaro-B	Serial Data Gateway Module	√	√	√	√
OPEL\2016\Vivaro-B	Info Display Module	√	√	√	√
OPEL\2016\Vivaro-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2016\Zafira-C	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2016\Zafira-C	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2016\Zafira-C	Engine Control Module\1.6L (LGE)	√	√	√	√
OPEL\2016\Zafira-C	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2016\Zafira-C	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2016\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2016\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2016\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2016\Zafira-C	Chassis Control Module	√	√	√	√
OPEL\2016\Zafira-C	Electronic Brake Control Module	√	√	√	√
OPEL\2016\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2016\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2016\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2016\Zafira-C	Body Control Module	√	√	√	√
OPEL\2016\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2016\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2016\Zafira-C	Headlamp Control Module	√	√	√	√
OPEL\2016\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2016\Zafira-C	Radio\Chime (UL5)	√	√	√	
OPEL\2016\Zafira-C	Radio\Radio	√	√	√	√
OPEL\2016\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2016\Zafira-C	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2016\Zafira-C	HVAC Control Module	√	√	√	√
OPEL\2016\Zafira-C	Front Seat Heating Control Module	√	√	√	√

OPEL\2016\Zafira-C	Parking Assist Control Module	√	√	√	√
OPEL\2016\Zafira-C	Frontview Camera Module	√	√	√	√
OPEL\2016\Zafira-C	Special Vehicle Control Module	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.2L (LWD)	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.4L (L2Z)\Not Equipped	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.4L (L2Z)\Stop/Start System (KL9)	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2015\Adam	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Adam	Transmission Control Module	√	√	√	√
OPEL\2015\Adam	Fuel Injector Control Module	√	√	√	√
OPEL\2015\Adam	Chassis Control Module	√	√	√	√
OPEL\2015\Adam	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Adam	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Adam	Instrument Cluster	√	√	√	√
OPEL\2015\Adam	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Adam	Radio	√	√	√	√
OPEL\2015\Adam	HVAC Control Module	√	√	√	√
OPEL\2015\Adam	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2015\Adam	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2015\Adam	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2015\Adam	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2015\Ampera	Engine Control Module\1.4L (LUU)	√	√	√	√
OPEL\2015\Ampera	Transmission Control Module	√	√	√	√
OPEL\2015\Ampera	Chassis Control Module	√	√	√	√
OPEL\2015\Ampera	Hybrid Powertrain Control Module	√	√	√	√
OPEL\2015\Ampera	Hybrid Powertrain Control Module 2	√	√	√	√
OPEL\2015\Ampera	Auxiliary Transmission Fluid Pump	√	√	√	√
OPEL\2015\Ampera	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Ampera	Parking Brake Control Module	√	√	√	√
OPEL\2015\Ampera	Power Steering Control Module	√	√	√	√
OPEL\2015\Ampera	Body Control Module	√	√	√	√
OPEL\2015\Ampera	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Ampera	Instrument Cluster	√	√	√	√
OPEL\2015\Ampera	Radio	√	√	√	√
OPEL\2015\Ampera	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Ampera	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2015\Ampera	HVAC Control Module	√	√	√	√
OPEL\2015\Ampera	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Ampera	Electric A/C Compressor Control Module	√			√
OPEL\2015\Ampera	Keyless Entry Control Module	√	√	√	√
OPEL\2015\Ampera	Battery Charger Control Module	√			√
OPEL\2015\Ampera	Parking Assist Control Module	√	√	√	√
OPEL\2015\Ampera	Frontview Camera Module	√	√	√	√
OPEL\2015\Ampera	Steering Column Lock Control Module	√	√	√	√
OPEL\2015\Ampera	Battery Energy Control Module	√			√
OPEL\2015\Ampera	Coolant Heater Control Module	√	√	√	√
OPEL\2015\Ampera	Drive Motor Control Module 1	√	√	√	√

OPEL\2015\Ampera	Drive Motor Control Module 2	√	√	√	√
OPEL\2015\Antara	Engine Control Module\2.4L (LE9)	√	√	√	√
OPEL\2015\Antara	Engine Control Module\2.0L (LNP)	√	√	√	√
OPEL\2015\Antara	Engine Control Module\3.0L (LFW)	√	√	√	√
OPEL\2015\Antara	Transmission Control Module	√	√	√	√
OPEL\2015\Antara	Chassis Control Module	√	√	√	√
OPEL\2015\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2015\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2015\Antara	Body Control Module	√	√	√	√
OPEL\2015\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2015\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Antara	Instrument Cluster	√	√	√	√
OPEL\2015\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2015\Antara	Headlamp Control Module	√	√	√	√
OPEL\2015\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2015\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2015\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2015\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2015\Antara	Radio\CDC 40 Opera	√	√	√	√
OPEL\2015\Antara	Radio\DVD 100 NAVI	√	√	√	√
OPEL\2015\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2015\Antara	Radio\None	√	√	√	√
OPEL\2015\Antara	HVAC Control Module	√	√	√	
OPEL\2015\Antara	Remote Control Door Lock Receiver\Not Equipped	√	√	√	√
OPEL\2015\Antara	Remote Control Door Lock Receiver\Tire Pressure Monitoring System - Manual Learn (UJM)	√	√	√	√
OPEL\2015\Antara	Parking Assist Control Module	√	√	√	√
OPEL\2015\Antara	Mobile Telephone Control Module	√	√	√	
OPEL\2015\Astra-J	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LDE)\Not Equipped	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LDE)\Stop/Start System (KL9)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.7L (LUD)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.7L (LUE)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.7L (LKR)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LVM)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2015\Astra-J	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2015\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2015\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2015\Astra-J	Fuel Injector Control Module	√			√

OPEL\2015\Astra-J	Chassis Control Module	√	√	√	√
OPEL\2015\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2015\Astra-J	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2015\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2015\Astra-J	Body Control Module	√	√	√	√
OPEL\2015\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2015\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2015\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2015\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Astra-J	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Astra-J	Radio\Radio	√	√	√	√
OPEL\2015\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2015\Astra-J	HVAC Control Module	√	√	√	√
OPEL\2015\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2015\Astra-J	Frontview Camera Module	√	√	√	√
OPEL\2015\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2015\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2015\Cascada	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2015\Cascada	Transmission Control Module\Transmission Control Module - AF40	√	√	√	√
OPEL\2015\Cascada	Chassis Control Module	√	√	√	√
OPEL\2015\Cascada	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Cascada	Parking Brake Control Module	√	√	√	√
OPEL\2015\Cascada	Power Steering Control Module	√	√	√	√
OPEL\2015\Cascada	Body Control Module	√	√	√	√
OPEL\2015\Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Cascada	Instrument Cluster	√	√	√	√
OPEL\2015\Cascada	Headlamp Control Module	√	√	√	√
OPEL\2015\Cascada	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Cascada	Radio\Radio	√	√	√	√
OPEL\2015\Cascada	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Cascada	Multimedia Player Interface Module	√	√	√	√
OPEL\2015\Cascada	HVAC Control Module	√	√	√	√
OPEL\2015\Cascada	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Cascada	Parking Assist Control Module	√	√	√	√
OPEL\2015\Cascada	Frontview Camera Module	√	√	√	√
OPEL\2015\Cascada	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2015\Cascada	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\1.4L (LUS)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\1.6L (LJ5)	√	√	√	√
OPEL\2015\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2015\Combo-D	Transmission Control Module	√	√	√	√

OPEL\2015\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2015\Combo-D	Electronic Brake Control Module\Vehicle Stability System (FX3)	√	√	√	√
OPEL\2015\Combo-D	Body Control Module	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.2L (LDC)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.4L (LDD)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.0L (LE1)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.3L (LKU)	√	√	√	√
OPEL\2015\Corsa-E	Engine Control Module\1.3L (LKV)	√	√	√	√
OPEL\2015\Corsa-E	Transmission Control Module\Automatic\Automatic Transmission T-76	√	√	√	√
OPEL\2015\Corsa-E	Transmission Control Module\Automatic\Manual Transmission Automatically Shifted	√	√	√	√
OPEL\2015\Corsa-E	Chassis Control Module	√	√	√	√
OPEL\2015\Corsa-E	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Corsa-E	Body Control Module	√	√	√	√
OPEL\2015\Corsa-E	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Corsa-E	Instrument Cluster	√	√	√	√
OPEL\2015\Corsa-E	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Corsa-E	Radio\Radio (UF7)	√	√	√	√
OPEL\2015\Corsa-E	Radio\Radio (UH7)	√	√	√	√
OPEL\2015\Corsa-E	Radio\Radio (UM7)	√	√	√	√
OPEL\2015\Corsa-E	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Corsa-E	HVAC Control Module	√	√	√	√
OPEL\2015\Corsa-E	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2015\Corsa-E	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2015\Corsa-E	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2015\Corsa-E	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2015\Corsa-E	Frontview Camera Module	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LTG)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LHV)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2015\Insignia	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2015\Insignia	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2015\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T43 (M7U M7W)	√	√	√	√

OPEL\2015\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2015\Insignia	Fuel Injector Control Module	√			√
OPEL\2015\Insignia	Chassis Control Module	√	√	√	√
OPEL\2015\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2015\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2015\Insignia	Power Steering Control Module	√	√	√	√
OPEL\2015\Insignia	Body Control Module	√	√	√	√
OPEL\2015\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Insignia	Instrument Cluster	√	√	√	√
OPEL\2015\Insignia	Radio Controls	√	√	√	√
OPEL\2015\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2015\Insignia	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Insignia	Radio	√	√	√	√
OPEL\2015\Insignia	Amplifier	√	√	√	√
OPEL\2015\Insignia	Human Machine Interface Control Module	√	√	√	√
OPEL\2015\Insignia	HVAC Control Module	√	√	√	√
OPEL\2015\Insignia	Keyless Entry Control Module\Standard Range Passive Entry (ATS)	√	√	√	√
OPEL\2015\Insignia	Left Side Object Detection Control Module	√	√	√	
OPEL\2015\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2015\Insignia	Frontview Camera Module	√	√	√	√
OPEL\2015\Insignia	Steering Column Lock Control Module	√	√	√	√
OPEL\2015\Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√
OPEL\2015\Insignia	HVAC Controls	√	√	√	√
OPEL\2015\Insignia	Infotainment Control Touchpad	√	√	√	√
OPEL\2015\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2015\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.3L (LDV)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.3L (LSF)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.4L (LDD)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.4L (LUH)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.4L (LUJ)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.6L (LVL)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.6L (LVM)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.6L (LWQ)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Not Equipped\1.7L (LPL)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.3L (LDV)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.3L (LSF)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.4L (LDD)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.4L (LUH)	√	√	√	√

OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.4L (LUJ)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.6L (LVL)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.6L (LVM)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.6L (LWQ)	√	√	√	√
OPEL\2015\Meriva-B	Engine Control Module\Stop/Start System (KL9)\1.7L (LPL)	√	√	√	√
OPEL\2015\Meriva-B	Fuel Injector Control Module	√			√
OPEL\2015\Meriva-B	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Meriva-B	Parking Brake Control Module	√	√	√	√
OPEL\2015\Meriva-B	Power Steering Control Module	√	√	√	√
OPEL\2015\Meriva-B	Body Control Module	√	√	√	√
OPEL\2015\Meriva-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Meriva-B	Instrument Cluster	√	√	√	√
OPEL\2015\Meriva-B	Headlamp Control Module	√	√	√	√
OPEL\2015\Meriva-B	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Meriva-B	Radio\Radio	√	√	√	√
OPEL\2015\Meriva-B	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Meriva-B	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Meriva-B	Multimedia Player Interface Module	√	√	√	√
OPEL\2015\Meriva-B	HVAC Control Module\Auto Control Dual Zone (CJ2)	√	√	√	√
OPEL\2015\Meriva-B	HVAC Control Module\Manual Control Single Zone (C67)	√	√	√	√
OPEL\2015\Meriva-B	HVAC Control Module\Manual Control Heater Only (C42)	√	√	√	√
OPEL\2015\Meriva-B	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Meriva-B	Parking Assist Control Module	√	√	√	√
OPEL\2015\Meriva-B	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2015\Meriva-B	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.7L (LUD)	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.8L (2H0)\2WD - Front	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.8L (2H0)\AWD (F46)	√	√	√	√
OPEL\2015\Mokka	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2015\Mokka	Transmission Control Module	√	√	√	√
OPEL\2015\Mokka	Fuel Injector Control Module	√			√
OPEL\2015\Mokka	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2015\Mokka	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Mokka	Power Steering Control Module	√	√	√	√
OPEL\2015\Mokka	Body Control Module	√	√	√	√
OPEL\2015\Mokka	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Mokka	Instrument Cluster	√	√	√	√
OPEL\2015\Mokka	Headlamp Control Module	√	√	√	√
OPEL\2015\Mokka	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Mokka	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Mokka	Radio\Radio	√	√	√	√
OPEL\2015\Mokka	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Mokka	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Mokka	Parking Assist Control Module	√	√	√	√
OPEL\2015\Mokka	Frontview Camera Module	√	√	√	√
OPEL\2015\Movano-B	Engine Control Module\2.3L (L2U)	√	√	√	√
OPEL\2015\Movano-B	Engine Control Module\2.3L (LWJ)	√	√	√	√

OPEL\2015\Movano-B	Engine Control Module\2.3L (LWL)	√	√	√	√
OPEL\2015\Movano-B	Engine Control Module\2.3L (L0B)	√	√	√	√
OPEL\2015\Movano-B	Engine Control Module\2.3L (L0C)	√	√	√	√
OPEL\2015\Movano-B	Engine Control Module\2.3L (L0D)	√	√	√	√
OPEL\2015\Movano-B	Transmission Control Module\Front Wheel Drive (FWD)	√	√	√	√
OPEL\2015\Movano-B	Transmission Control Module\Rear Wheel Drive (RWL)	√	√	√	√
OPEL\2015\Movano-B	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Movano-B	Body Control Module	√	√	√	√
OPEL\2015\Movano-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2015\Movano-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Movano-B	Instrument Cluster	√	√	√	√
OPEL\2015\Movano-B	Radio\R15 BT USB (UF7)	√	√	√	√
OPEL\2015\Movano-B	Radio\CD35 BT USB (UGI)	√	√	√	√
OPEL\2015\Movano-B	Radio\CD16 BT USB DAB (2L6)	√	√	√	√
OPEL\2015\Movano-B	Radio\CD16 BT USB (2L7)	√	√	√	√
OPEL\2015\Movano-B	HVAC Control Module\Auto Control Single Zone (C61)	√	√	√	√
OPEL\2015\Movano-B	HVAC Control Module\Manual Control Single Zone (C60)	√	√	√	√
OPEL\2015\Movano-B	Parking Assist Control Module	√	√	√	√
OPEL\2015\Movano-B	Serial Data Gateway Module	√	√	√	√
OPEL\2015\Movano-B	Navigation Control Module	√	√	√	√
OPEL\2015\Movano-B	Tire Pressure Indicator Module	√	√	√	√
OPEL\2015\Movano-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2015\Vivaro-B	Engine Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Body Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Auxiliary Body Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Vivaro-B	Instrument Cluster	√	√	√	√
OPEL\2015\Vivaro-B	Radio\R16 BT USB (2L4)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\CD18 BT USB (2L0)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\R16 BT USB DAB (2L1)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\CD18 BT USB DAB (2L2)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\Navi 50 (UN1)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\Navi 80 IntelliLink (2L3)	√	√	√	√
OPEL\2015\Vivaro-B	Radio\Navi 80 IntelliLink (2L5)	√	√	√	√
OPEL\2015\Vivaro-B	HVAC Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Keyless Entry Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Parking Assist Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Auxiliary Heater Control Module	√	√	√	√
OPEL\2015\Vivaro-B	Serial Data Gateway Module	√	√	√	√
OPEL\2015\Vivaro-B	Multifunction Accessory Control Module	√	√	√	
OPEL\2015\Vivaro-B	Info Display Module	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.6L (LGE)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2015\Zafira-C	Engine Control Module\2.0L (LFS)	√	√	√	√
OPEL\2015\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√

OPEL\2015\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2015\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2015\Zafira-C	Chassis Control Module	√	√	√	√
OPEL\2015\Zafira-C	Electronic Brake Control Module	√	√	√	√
OPEL\2015\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2015\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2015\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2015\Zafira-C	Body Control Module	√	√	√	√
OPEL\2015\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2015\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2015\Zafira-C	Headlamp Control Module	√	√	√	√
OPEL\2015\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2015\Zafira-C	Radio\Chime (UL5)	√	√	√	
OPEL\2015\Zafira-C	Radio\Radio	√	√	√	√
OPEL\2015\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2015\Zafira-C	Multimedia Player Interface Module	√	√	√	√
OPEL\2015\Zafira-C	HVAC Control Module	√	√	√	√
OPEL\2015\Zafira-C	Front Seat Heating Control Module	√	√	√	√
OPEL\2015\Zafira-C	Frontview Camera Module	√	√	√	√
OPEL\2015\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2015\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2014\Astra-H	Engine-Z 12 XEP		√	√	
OPEL\2014\Astra-H	Engine-Y 13 DTH		√	√	
OPEL\2014\Astra-H	Engine-Z 13 DTH		√	√	
OPEL\2014\Astra-H	Engine-Z 14 XEL		√	√	
OPEL\2014\Astra-H	Engine-Z 14 XEP		√	√	
OPEL\2014\Astra-H	Engine-Z 16 LET		√	√	
OPEL\2014\Astra-H	Engine-Z 16 XE1		√	√	
OPEL\2014\Astra-H	Engine-Z 16 XEP		√	√	
OPEL\2014\Astra-H	Engine-Z 16 XER		√	√	
OPEL\2014\Astra-H	Engine-A 16 LET		√	√	
OPEL\2014\Astra-H	Engine-A 16 XER		√	√	
OPEL\2014\Astra-H	Engine-Z 17 DTH		√	√	
OPEL\2014\Astra-H	Engine-Z 17 DTJ		√	√	
OPEL\2014\Astra-H	Engine-Z 17 DTL		√	√	
OPEL\2014\Astra-H	Engine-Z 17 DTR		√	√	
OPEL\2014\Astra-H	Engine-A 17 DTJ		√	√	
OPEL\2014\Astra-H	Engine-A 17 DTR		√	√	
OPEL\2014\Astra-H	Engine-Z 18 XE		√	√	
OPEL\2014\Astra-H	Engine-Z 18 XER		√	√	
OPEL\2014\Astra-H	Engine-A 18 XER		√	√	
OPEL\2014\Astra-H	Engine-Z 19 DT		√	√	
OPEL\2014\Astra-H	Engine-Z 19 DTH		√	√	
OPEL\2014\Astra-H	Engine-Z 20 LEH		√	√	
OPEL\2014\Astra-H	Engine-Z 20 LEL		√	√	
OPEL\2014\Astra-H	Engine-Z 20 LER		√	√	
OPEL\2014\Astra-H	Engine-Z 22 YH		√	√	
OPEL\2014\Astra-H	Engine-Engine(default)		√	√	
OPEL\2014\Astra-H	Transmission-AF 40-6		√	√	
OPEL\2014\Astra-H	Transmission-AF17-4		√	√	
OPEL\2014\Astra-H	Transmission-AF 22-4		√	√	
OPEL\2014\Astra-H	Transmission-MTA(Easytronic)		√	√	
OPEL\2014\Astra-H	Transmission-MTA(Easytronic Magneti Marelli)		√	√	
OPEL\2014\Astra-H	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	

OPEL\2014\Astra-H	Chassis-TPMS (Tyre Pressure Monitoring System)		√	√	
OPEL\2014\Astra-H	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2014\Astra-H	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2014\Astra-H	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2014\Astra-H	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2014\Astra-H	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2014\Astra-H	Body-IL (Interior Lighting)		√	√	
OPEL\2014\Astra-H	Body-W&W (Wipers/Washer)		√	√	
OPEL\2014\Astra-H	Body-CDL (Central Door Lock)		√	√	
OPEL\2014\Astra-H	Body-IC (Instrument Cluster)		√	√	
OPEL\2014\Astra-H	Body-Immobiliser		√	√	
OPEL\2014\Astra-H	Body-CIM (Steering Column Module)		√	√	
OPEL\2014\Astra-H	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2014\Astra-H	Body-EHHT (Electrohydraulic HardTop)		√	√	
OPEL\2014\Astra-H	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2014\Astra-H	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2014\Astra-H	Body-EHS (Electrical Heater System)		√	√	
OPEL\2014\Astra-H	Body-PAS (Park Pilot)		√	√	
OPEL\2014\Astra-H	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2014\Astra-H	Body-SLM (Shift Lever Module)		√	√	
OPEL\2014\Astra-H	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2014\Astra-H	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2014\Astra-H	Body-PEPS (Open&Start)		√	√	
OPEL\2014\Corsa-D	Engine-Z 10 XEP		√	√	
OPEL\2014\Corsa-D	Engine-A 10 XEP		√	√	
OPEL\2014\Corsa-D	Engine-Z 12 XEP		√	√	
OPEL\2014\Corsa-D	Engine-A 12 XER		√	√	
OPEL\2014\Corsa-D	Engine-A 12 XEL		√	√	
OPEL\2014\Corsa-D	Engine-Z 13 DTH		√	√	
OPEL\2014\Corsa-D	Engine-Z 13 DTE		√	√	
OPEL\2014\Corsa-D	Engine-Z 13 DTJ		√	√	
OPEL\2014\Corsa-D	Engine-A 13 DTC		√	√	
OPEL\2014\Corsa-D	Engine-A 13 DTE		√	√	
OPEL\2014\Corsa-D	Engine-Z 14 XEP		√	√	
OPEL\2014\Corsa-D	Engine-A 14 XEL		√	√	
OPEL\2014\Corsa-D	Engine-A 14 XER		√	√	
OPEL\2014\Corsa-D	Engine-Z 16 LEL		√	√	
OPEL\2014\Corsa-D	Engine-Z 16 LER		√	√	
OPEL\2014\Corsa-D	Engine-A 16 LEL		√	√	
OPEL\2014\Corsa-D	Engine-A 16 LER		√	√	
OPEL\2014\Corsa-D	Engine-Z 17 DTR		√	√	
OPEL\2014\Corsa-D	Engine-Engine(default)		√	√	
OPEL\2014\Corsa-D	Transmission-AF 13-4		√	√	
OPEL\2014\Corsa-D	Transmission-MTA(Easytronic)		√	√	
OPEL\2014\Corsa-D	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2014\Corsa-D	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2014\Corsa-D	Body-XL (Exterior Lighting)		√	√	
OPEL\2014\Corsa-D	Body-IL (Interior Lighting)		√	√	
OPEL\2014\Corsa-D	Body-W&W (Wipers/Washer)		√	√	
OPEL\2014\Corsa-D	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2014\Corsa-D	Body-ATW (Anti Theft Warning System)		√	√	

OPEL\2014\Corsa-D	Body-CDL (Central Door Lock)		√	√	
OPEL\2014\Corsa-D	Body-Immobiliser		√	√	
OPEL\2014\Corsa-D	Body-AFL (Adaptive Forward Lighting)		√	√	
OPEL\2014\Corsa-D	Body-EHS (Electrical Heater System)		√	√	
OPEL\2014\Corsa-D	Body-IPC (Instrument)		√	√	
OPEL\2014\Corsa-D	Body-PAS (Park Pilot)		√	√	
OPEL\2014\Corsa-D	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2014\Corsa-D	Body-TIM (Trailer Interface Module)		√	√	
OPEL\2014\Corsa-D	Body-BCM (Body Control Module)		√	√	
OPEL\2014\Zafira-B	Engine-Z 16 XE1		√	√	
OPEL\2014\Zafira-B	Engine-Z 16 XEP		√	√	
OPEL\2014\Zafira-B	Engine-Z 16 XER		√	√	
OPEL\2014\Zafira-B	Engine-Z 16 YNG		√	√	
OPEL\2014\Zafira-B	Engine-A 16 XER		√	√	
OPEL\2014\Zafira-B	Engine-Z 17 DTJ		√	√	
OPEL\2014\Zafira-B	Engine-A 17 DTJ		√	√	
OPEL\2014\Zafira-B	Engine-A 17 DTR		√	√	
OPEL\2014\Zafira-B	Engine-Z 18 XER		√	√	
OPEL\2014\Zafira-B	Engine-A 18 XER		√	√	
OPEL\2014\Zafira-B	Engine-Z 19 DT		√	√	
OPEL\2014\Zafira-B	Engine-Z 19 DTH		√	√	
OPEL\2014\Zafira-B	Engine-Z 20 LEH		√	√	
OPEL\2014\Zafira-B	Engine-Z 20 LER		√	√	
OPEL\2014\Zafira-B	Engine-Z 22 YH		√	√	
OPEL\2014\Zafira-B	Engine-Engine(default)		√	√	
OPEL\2014\Zafira-B	Transmission-AF 40-6		√	√	
OPEL\2014\Zafira-B	Transmission-MTA(Easytronic)		√	√	
OPEL\2014\Zafira-B	Transmission-AF 22-4		√	√	
OPEL\2014\Zafira-B	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2014\Zafira-B	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	
OPEL\2014\Zafira-B	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2014\Zafira-B	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2014\Zafira-B	Chassis-CDC (Continuous Damping Control)		√	√	
OPEL\2014\Zafira-B	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2014\Zafira-B	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2014\Zafira-B	Body-IL (Interior Lighting)		√	√	
OPEL\2014\Zafira-B	Body-W&W (Wipers/Washer)		√	√	
OPEL\2014\Zafira-B	Body-CDL (Central Door Lock)		√	√	
OPEL\2014\Zafira-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2014\Zafira-B	Body-Immobiliser		√	√	
OPEL\2014\Zafira-B	Body-CIM (Steering Column Module)		√	√	
OPEL\2014\Zafira-B	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2014\Zafira-B	Body-EHS (Electrical Heater System)		√	√	
OPEL\2014\Zafira-B	Body-PAS (Park Pilot)		√	√	
OPEL\2014\Zafira-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2014\Zafira-B	Body-SLM (Shift Lever Module)		√	√	
OPEL\2014\Zafira-B	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2014\Zafira-B	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2014\Zafira-B	Body-PEPS (Open&Start)		√	√	
OPEL\2014\Zafira-B	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2014\Zafira-B	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2014\Adam	Engine Control Module\1.2L (LWD)	√	√	√	√

OPEL\2014\Adam	Engine Control Module\1.4L (L2Z)\Not Equipped	√	√	√	√
OPEL\2014\Adam	Engine Control Module\1.4L (L2Z)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Adam	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2014\Adam	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Adam	Fuel Injector Control Module	√			√
OPEL\2014\Adam	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Adam	Body Control Module	√	√	√	√
OPEL\2014\Adam	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Adam	Instrument Cluster	√	√	√	√
OPEL\2014\Adam	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Adam	Radio	√	√	√	√
OPEL\2014\Adam	HVAC Control Module	√	√	√	√
OPEL\2014\Adam	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2014\Adam	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2014\Adam	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2014\Ampera	Engine Control Module	√	√	√	√
OPEL\2014\Ampera	Transmission Control Module	√	√	√	√
OPEL\2014\Ampera	Chassis Control Module	√	√	√	√
OPEL\2014\Ampera	Hybrid Powertrain Control Module	√	√	√	√
OPEL\2014\Ampera	Hybrid Powertrain Control Module 2	√	√	√	√
OPEL\2014\Ampera	Auxiliary Transmission Fluid Pump	√	√	√	√
OPEL\2014\Ampera	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Ampera	Parking Brake Control Module	√	√	√	√
OPEL\2014\Ampera	Power Steering Control Module	√	√	√	√
OPEL\2014\Ampera	Body Control Module	√	√	√	√
OPEL\2014\Ampera	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Ampera	Instrument Cluster	√	√	√	√
OPEL\2014\Ampera	Radio	√	√	√	√
OPEL\2014\Ampera	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Ampera	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2014\Ampera	HVAC Control Module	√	√	√	√
OPEL\2014\Ampera	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Ampera	Electric A/C Compressor Control Module	√			√
OPEL\2014\Ampera	Keyless Entry Control Module	√	√	√	√
OPEL\2014\Ampera	Battery Charger Control Module	√			√
OPEL\2014\Ampera	Parking Assist Control Module	√	√	√	√
OPEL\2014\Ampera	Frontview Camera Module	√	√	√	√
OPEL\2014\Ampera	Steering Column Lock Control Module	√	√	√	√
OPEL\2014\Ampera	Battery Energy Control Module	√			√
OPEL\2014\Ampera	Coolant Heater Control Module	√	√	√	√
OPEL\2014\Ampera	Drive Motor Control Module 1	√	√	√	√
OPEL\2014\Ampera	Drive Motor Control Module 2	√	√	√	√
OPEL\2014\Antara	Engine Control Module\2.4L (LE9)	√	√	√	√
OPEL\2014\Antara	Engine Control Module\2.0L (LNP)	√	√	√	√
OPEL\2014\Antara	Engine Control Module\2.2L (LNQ)	√	√	√	√
OPEL\2014\Antara	Engine Control Module\3.0L (LFW)	√	√	√	√
OPEL\2014\Antara	Transmission Control Module	√	√	√	√
OPEL\2014\Antara	Chassis Control Module	√	√	√	√

OPEL\2014\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2014\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2014\Antara	Body Control Module	√	√	√	√
OPEL\2014\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2014\Antara	Instrument Cluster	√	√	√	√
OPEL\2014\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2014\Antara	Headlamp Control Module	√	√	√	√
OPEL\2014\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2014\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2014\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2014\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2014\Antara	Radio\DVD 100 NAVI	√	√	√	√
OPEL\2014\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2014\Antara	Radio\CDC 40 Opera	√	√	√	√
OPEL\2014\Antara	Radio\None	√	√	√	√
OPEL\2014\Antara	HVAC Control Module	√	√	√	
OPEL\2014\Antara	Remote Control Door Lock Receiver\Not Equipped	√	√	√	√
OPEL\2014\Antara	Remote Control Door Lock Receiver\Tire Pressure Monitoring System - Manual Learn (UJM)	√	√	√	√
OPEL\2014\Antara	Parking Assist Control Module	√	√	√	√
OPEL\2014\Antara	Mobile Telephone Control Module	√	√	√	
OPEL\2014\Astra-J	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LDE)\Not Equipped	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LDE)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.7L (LKR)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.7L (LUD)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.7L (LUE)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LVM)	√	√	√	√
OPEL\2014\Astra-J	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2014\Astra-J	Transmission Control Module\Automatic Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2014\Astra-J	Fuel Injector Control Module	√			√
OPEL\2014\Astra-J	Chassis Control Module	√	√	√	√
OPEL\2014\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2014\Astra-J	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2014\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2014\Astra-J	Body Control Module	√	√	√	√
OPEL\2014\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2014\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√

OPEL\2014\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2014\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Astra-J	Radio\Radio	√	√	√	√
OPEL\2014\Astra-J	Radio\Chime (UL5)	√	√	√	
OPEL\2014\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2014\Astra-J	HVAC Control Module	√	√	√	√
OPEL\2014\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2014\Astra-J	Frontview Camera Module	√	√	√	√
OPEL\2014\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2014\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2014\Astra-J	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2014\Cascada	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2014\Cascada	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2014\Cascada	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2014\Cascada	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2014\Cascada	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2014\Cascada	Transmission Control Module\Transmission Control Module - AF40	√	√	√	√
OPEL\2014\Cascada	Transmission Control Module\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2014\Cascada	Chassis Control Module	√	√	√	√
OPEL\2014\Cascada	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Cascada	Parking Brake Control Module	√	√	√	√
OPEL\2014\Cascada	Power Steering Control Module	√	√	√	√
OPEL\2014\Cascada	Body Control Module	√	√	√	√
OPEL\2014\Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Cascada	Instrument Cluster	√	√	√	√
OPEL\2014\Cascada	Radio\Radio	√	√	√	√
OPEL\2014\Cascada	Radio\Chime (UL5)	√	√	√	
OPEL\2014\Cascada	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Cascada	Multimedia Player Interface Module	√	√	√	√
OPEL\2014\Cascada	HVAC Control Module	√	√	√	√
OPEL\2014\Cascada	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Cascada	Parking Assist Control Module	√	√	√	√
OPEL\2014\Cascada	Frontview Camera Module	√	√	√	√
OPEL\2014\Cascada	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2014\Cascada	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2014\Cascada	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\1.4L (LUS)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\1.6L (LJ5)	√	√	√	√
OPEL\2014\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2014\Combo-D	Transmission Control Module	√	√	√	√
OPEL\2014\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2014\Combo-D	Electronic Brake Control Module\Vehicle Stability System (FX3)	√	√	√	√
OPEL\2014\Combo-D	Body Control Module	√	√	√	√

OPEL\2014\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LHV)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\2.0L (LTG)	√	√	√	√
OPEL\2014\Insignia	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2014\Insignia	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2014\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2014\Insignia	Transmission Control Module\Automatic\Transmission Control Module - T43 (M7U M7W)	√	√	√	√
OPEL\2014\Insignia	Fuel Injector Control Module	√			√
OPEL\2014\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2014\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2014\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2014\Insignia	Power Steering Control Module	√	√	√	√
OPEL\2014\Insignia	Body Control Module	√	√	√	√
OPEL\2014\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Insignia	Instrument Cluster	√	√	√	√
OPEL\2014\Insignia	Radio Controls	√	√	√	√
OPEL\2014\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2014\Insignia	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Insignia	Radio	√	√	√	√
OPEL\2014\Insignia	Amplifier	√	√	√	√
OPEL\2014\Insignia	Human Machine Interface Control Module	√	√	√	√
OPEL\2014\Insignia	HVAC Control Module	√	√	√	√
OPEL\2014\Insignia	Keyless Entry Control Module\Standard Range Passive Entry (ATS)	√	√	√	√
OPEL\2014\Insignia	Left Side Object Detection Control Module	√	√	√	
OPEL\2014\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2014\Insignia	Frontview Camera Module	√	√	√	√
OPEL\2014\Insignia	Steering Column Lock Control Module	√	√	√	√
OPEL\2014\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2014\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2014\Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√
OPEL\2014\Insignia	HVAC Controls	√	√	√	√
OPEL\2014\Insignia	Infotainment Control Touchpad	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.3L (LDV)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√

OPEL\2014\Meriva-B	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.4L (LUH)\Not Equipped	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.4L (LUH)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.4L (LUJ)\Not Equipped	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.4L (LUJ)\Stop/Start System (KL9)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.6L (LVM)	√	√	√	√
OPEL\2014\Meriva-B	Engine Control Module\1.7L (LPL)	√	√	√	√
OPEL\2014\Meriva-B	Transmission Control Module	√	√	√	√
OPEL\2014\Meriva-B	Fuel Injector Control Module	√			√
OPEL\2014\Meriva-B	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Meriva-B	Power Steering Control Module	√	√	√	√
OPEL\2014\Meriva-B	Body Control Module	√	√	√	√
OPEL\2014\Meriva-B	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Meriva-B	Instrument Cluster	√	√	√	√
OPEL\2014\Meriva-B	Headlamp Control Module	√	√	√	√
OPEL\2014\Meriva-B	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Meriva-B	Radio\Radio	√	√	√	√
OPEL\2014\Meriva-B	Radio\Chime (UL5)	√	√	√	
OPEL\2014\Meriva-B	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Meriva-B	Multimedia Player Interface Module	√	√	√	√
OPEL\2014\Meriva-B	HVAC Control Module\Auto Control Dual Zone (CJ2)	√	√	√	√
OPEL\2014\Meriva-B	HVAC Control Module\Manual Control Single Zone (C67)	√	√	√	√
OPEL\2014\Meriva-B	HVAC Control Module\Manual Control Heater Only (C42)	√	√	√	√
OPEL\2014\Meriva-B	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Meriva-B	Parking Assist Control Module	√	√	√	√
OPEL\2014\Meriva-B	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2014\Meriva-B	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2014\Mokka	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2014\Mokka	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2014\Mokka	Engine Control Module\1.7L (LUD)	√	√	√	√
OPEL\2014\Mokka	Engine Control Module\1.8L (2H0)\2WD - Front	√	√	√	√
OPEL\2014\Mokka	Engine Control Module\1.8L (2H0)\AWD (F46)	√	√	√	√
OPEL\2014\Mokka	Transmission Control Module	√	√	√	√
OPEL\2014\Mokka	Fuel Injector Control Module	√			√
OPEL\2014\Mokka	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2014\Mokka	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Mokka	Power Steering Control Module	√	√	√	√
OPEL\2014\Mokka	Body Control Module	√	√	√	√
OPEL\2014\Mokka	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Mokka	Instrument Cluster	√	√	√	√
OPEL\2014\Mokka	Headlamp Control Module	√	√	√	√
OPEL\2014\Mokka	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Mokka	Radio\Radio	√	√	√	√
OPEL\2014\Mokka	Radio\Chime (UL5)	√	√	√	
OPEL\2014\Mokka	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Mokka	HVAC Control Module	√	√	√	√
OPEL\2014\Mokka	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Mokka	Parking Assist Control Module	√	√	√	√

OPEL\2014\Mokka	Frontview Camera Module	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\1.6L (LGE)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2014\Zafira-C	Engine Control Module\1.6L (LWC)	√	√	√	√
OPEL\2014\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2014\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2014\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2014\Zafira-C	Chassis Control Module	√	√	√	√
OPEL\2014\Zafira-C	Electronic Brake Control Module	√	√	√	√
OPEL\2014\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2014\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2014\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2014\Zafira-C	Body Control Module	√	√	√	√
OPEL\2014\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2014\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2014\Zafira-C	Headlamp Control Module	√	√	√	√
OPEL\2014\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2014\Zafira-C	Radio\Radio	√	√	√	√
OPEL\2014\Zafira-C	Radio\Chime (UL5)	√	√	√	
OPEL\2014\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2014\Zafira-C	Multimedia Player Interface Module	√	√	√	√
OPEL\2014\Zafira-C	HVAC Control Module	√	√	√	√
OPEL\2014\Zafira-C	Front Seat Heating Control Module	√	√	√	√
OPEL\2014\Zafira-C	Parking Assist Control Module	√	√	√	√
OPEL\2014\Zafira-C	Frontview Camera Module	√	√	√	√
OPEL\2014\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2014\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2014\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2013\Zafira-B	Engine-Z 16 XE1		√	√	
OPEL\2013\Zafira-B	Engine-Z 16 XEP		√	√	
OPEL\2013\Zafira-B	Engine-Z 16 XER		√	√	
OPEL\2013\Zafira-B	Engine-A 16 XER		√	√	
OPEL\2013\Zafira-B	Engine-Z 17 DTJ		√	√	
OPEL\2013\Zafira-B	Engine-A 17 DTJ		√	√	
OPEL\2013\Zafira-B	Engine-A 17 DTR		√	√	
OPEL\2013\Zafira-B	Engine-Z 18 XER		√	√	
OPEL\2013\Zafira-B	Engine-A 18 XER		√	√	
OPEL\2013\Zafira-B	Engine-Z 19 DT		√	√	
OPEL\2013\Zafira-B	Engine-Z 19 DTH		√	√	
OPEL\2013\Zafira-B	Engine-Z 20 LEH		√	√	
OPEL\2013\Zafira-B	Engine-Z 20 LER		√	√	
OPEL\2013\Zafira-B	Engine-Z 22 YH		√	√	
OPEL\2013\Zafira-B	Engine-Engine(default)		√	√	
OPEL\2013\Zafira-B	Transmission-AF 40-6		√	√	
OPEL\2013\Zafira-B	Transmission-MTA(Easytronic)		√	√	
OPEL\2013\Zafira-B	Transmission-AF 22-4		√	√	

OPEL\2013\Zafira-B	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2013\Zafira-B	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	
OPEL\2013\Zafira-B	Chassis-TPMS (Tyre Pressure Monitoring System)		√	√	
OPEL\2013\Zafira-B	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2013\Zafira-B	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2013\Zafira-B	Chassis-CDC (Continuous Damping Control)		√	√	
OPEL\2013\Zafira-B	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2013\Zafira-B	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2013\Zafira-B	Body-IL (Interior Lighting)		√	√	
OPEL\2013\Zafira-B	Body-W&W (Wipers/Washer)		√	√	
OPEL\2013\Zafira-B	Body-CDL (Central Door Lock)		√	√	
OPEL\2013\Zafira-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2013\Zafira-B	Body-Immobiliser		√	√	
OPEL\2013\Zafira-B	Body-CIM (Steering Column Module)		√	√	
OPEL\2013\Zafira-B	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2013\Zafira-B	Body-EHS (Electrical Heater System)		√	√	
OPEL\2013\Zafira-B	Body-PAS (Park Pilot)		√	√	
OPEL\2013\Zafira-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2013\Zafira-B	Body-SLM (Shift Lever Module)		√	√	
OPEL\2013\Zafira-B	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2013\Zafira-B	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2013\Zafira-B	Body-PEPS (Open&Start)		√	√	
OPEL\2013\Zafira-B	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2013\Zafira-B	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2013\Vivaro	Body-PP (Park Pilot)		√	√	
OPEL\2013\Vivaro	Body-AOH (Add On Heater)		√	√	
OPEL\2013\Vivaro	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2013\Meriva-B	Engine-A 13 DTC 1.3(LDV)		√	√	
OPEL\2013\Meriva-B	Engine-A 13 DTE 1.3(LSF)		√	√	
OPEL\2013\Meriva-B	Engine-A 14 NEL (LUH)		√	√	
OPEL\2013\Meriva-B	Engine-A 14 NET (LUJ)		√	√	
OPEL\2013\Meriva-B	Engine-A 14 XER (LDD)		√	√	
OPEL\2013\Meriva-B	Engine-A 17 DTC 1.7(LUE)		√	√	
OPEL\2013\Meriva-B	Engine-A 17 DTS 1.7(LUD)		√	√	
OPEL\2013\Meriva-B	Engine-ECM (Engine Control Module)		√	√	
OPEL\2013\Meriva-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2013\Meriva-B	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2013\Meriva-B	Chassis-EPS (Electric Power Steering)		√	√	
OPEL\2013\Meriva-B	Chassis-PBCM (Parking Brake Control Module)		√	√	
OPEL\2013\Meriva-B	Chassis-SWASM (Steering Wheel Angle Sensor Module)		√	√	
OPEL\2013\Meriva-B	Body-FSHCM (Front Seat Heating Control Module)		√	√	
OPEL\2013\Meriva-B	Body-BCM (Body Control Module)		√	√	
OPEL\2013\Meriva-B	Body-HLCM (Headlamp Control Module)		√	√	
OPEL\2013\Meriva-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	

OPEL\2013\Meriva-B	Body-PACM (Parking Assist Control Module)		√	√	
OPEL\2013\Meriva-B	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2013\Meriva-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2013\Meriva-B	Body-TICM (Trailer Interface Control Module)		√	√	
OPEL\2013\Corsa-D	Engine-Z 10 XEP		√	√	
OPEL\2013\Corsa-D	Engine-A 10 XEP		√	√	
OPEL\2013\Corsa-D	Engine-Z 12 XEP		√	√	
OPEL\2013\Corsa-D	Engine-A 12 XER		√	√	
OPEL\2013\Corsa-D	Engine-A 12 XEL		√	√	
OPEL\2013\Corsa-D	Engine-Z 13 DTH		√	√	
OPEL\2013\Corsa-D	Engine-Z 13 DTE		√	√	
OPEL\2013\Corsa-D	Engine-Z 13 DTJ		√	√	
OPEL\2013\Corsa-D	Engine-A 13 DTC		√	√	
OPEL\2013\Corsa-D	Engine-A 13 DTE		√	√	
OPEL\2013\Corsa-D	Engine-Z 14 XEP		√	√	
OPEL\2013\Corsa-D	Engine-A 14 XEL		√	√	
OPEL\2013\Corsa-D	Engine-A 14 XER		√	√	
OPEL\2013\Corsa-D	Engine-Z 16 LEL		√	√	
OPEL\2013\Corsa-D	Engine-Z 16 LER		√	√	
OPEL\2013\Corsa-D	Engine-A 16 LER		√	√	
OPEL\2013\Corsa-D	Engine-Z 17 DTR		√	√	
OPEL\2013\Corsa-D	Engine-Engine(default)		√	√	
OPEL\2013\Corsa-D	Transmission-MTA(Easytronic Magneti Marelli)		√	√	
OPEL\2013\Corsa-D	Transmission-AF 13-4		√	√	
OPEL\2013\Corsa-D	Transmission-MTA(Easytronic)		√	√	
OPEL\2013\Corsa-D	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2013\Corsa-D	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2013\Corsa-D	Body-XL (Exterior Lighting)		√	√	
OPEL\2013\Corsa-D	Body-IL (Interior Lighting)		√	√	
OPEL\2013\Corsa-D	Body-W&W (Wipers/Washer)		√	√	
OPEL\2013\Corsa-D	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2013\Corsa-D	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2013\Corsa-D	Body-CDL (Central Door Lock)		√	√	
OPEL\2013\Corsa-D	Body-Immobiliser		√	√	
OPEL\2013\Corsa-D	Body-AFL (Adaptive Forward Lighting)		√	√	
OPEL\2013\Corsa-D	Body-EHS (Electrical Heater System)		√	√	
OPEL\2013\Corsa-D	Body-IPC (Instrument)		√	√	
OPEL\2013\Corsa-D	Body-PAS (Park Pilot)		√	√	
OPEL\2013\Corsa-D	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2013\Corsa-D	Body-TIM (Trailer Interface Module)		√	√	
OPEL\2013\Corsa-D	Body-BCM (Body Control Module)		√	√	
OPEL\2013\Astra-H	Engine-Z 12 XEP		√	√	
OPEL\2013\Astra-H	Engine-Y 13 DTH		√	√	
OPEL\2013\Astra-H	Engine-Z 13 DTH		√	√	
OPEL\2013\Astra-H	Engine-Z 14 XEL		√	√	
OPEL\2013\Astra-H	Engine-Z 14 XEP		√	√	
OPEL\2013\Astra-H	Engine-Z 16 LET		√	√	
OPEL\2013\Astra-H	Engine-Z 16 XE1		√	√	
OPEL\2013\Astra-H	Engine-Z 16 XEP		√	√	
OPEL\2013\Astra-H	Engine-Z 16 XER		√	√	
OPEL\2013\Astra-H	Engine-A 16 LET		√	√	
OPEL\2013\Astra-H	Engine-A 16 XER		√	√	
OPEL\2013\Astra-H	Engine-Z 17 DTH		√	√	
OPEL\2013\Astra-H	Engine-Z 17 DTJ		√	√	
OPEL\2013\Astra-H	Engine-Z 17 DTL		√	√	

OPEL\2013\Astra-H	Engine-Z 17 DTR		√	√	
OPEL\2013\Astra-H	Engine-A 17 DTJ		√	√	
OPEL\2013\Astra-H	Engine-A 17 DTR		√	√	
OPEL\2013\Astra-H	Engine-Z 18 XER		√	√	
OPEL\2013\Astra-H	Engine-A 18 XER		√	√	
OPEL\2013\Astra-H	Engine-Z 19 DT		√	√	
OPEL\2013\Astra-H	Engine-Z 19 DTH		√	√	
OPEL\2013\Astra-H	Engine-Z 20 LEH		√	√	
OPEL\2013\Astra-H	Engine-Z 20 LEL		√	√	
OPEL\2013\Astra-H	Engine-Z 20 LER		√	√	
OPEL\2013\Astra-H	Engine-Z 22 YH		√	√	
OPEL\2013\Astra-H	Engine-Engine(default)		√	√	
OPEL\2013\Astra-H	Transmission-AF 40-6		√	√	
OPEL\2013\Astra-H	Transmission-AF17-4		√	√	
OPEL\2013\Astra-H	Transmission-AF 22-4		√	√	
OPEL\2013\Astra-H	Transmission-MTA(Easytronic)		√	√	
OPEL\2013\Astra-H	Transmission-MTA(Easytronic Magneti Marelli)		√	√	
OPEL\2013\Astra-H	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	
OPEL\2013\Astra-H	Chassis-TPMS (Tyre Pressure Monitoring System)		√	√	
OPEL\2013\Astra-H	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2013\Astra-H	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2013\Astra-H	Chassis-CDC (Continuous Damping Control)		√	√	
OPEL\2013\Astra-H	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2013\Astra-H	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2013\Astra-H	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2013\Astra-H	Body-IL (Interior Lighting)		√	√	
OPEL\2013\Astra-H	Body-W&W (Wipers/Washer)		√	√	
OPEL\2013\Astra-H	Body-CDL (Central Door Lock)		√	√	
OPEL\2013\Astra-H	Body-IC (Instrument Cluster)		√	√	
OPEL\2013\Astra-H	Body-Immobiliser		√	√	
OPEL\2013\Astra-H	Body-CIM (Steering Column Module)		√	√	
OPEL\2013\Astra-H	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2013\Astra-H	Body-EHHT (Electrohydraulic HardTop)		√	√	
OPEL\2013\Astra-H	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2013\Astra-H	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2013\Astra-H	Body-EHS (Electrical Heater System)		√	√	
OPEL\2013\Astra-H	Body-PAS (Park Pilot)		√	√	
OPEL\2013\Astra-H	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2013\Astra-H	Body-SLM (Shift Lever Module)		√	√	
OPEL\2013\Astra-H	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2013\Astra-H	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2013\Astra-H	Body-PEPS (Open&Start)		√	√	
OPEL\2013\Agila-B	Engine-K12B		√	√	
OPEL\2013\Agila-B	Engine-D13A / Z 13 DTJ		√	√	
OPEL\2013\Agila-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2013\Agila-B	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2013\Agila-B	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2013\Agila-B	Body-BCM (Body Control Module)		√	√	
OPEL\2013\Agila-B	Body-Immobiliser		√	√	

OPEL\2013\Agila-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2013\Adam	Engine Control Module\1.4L (LDD)\Not Equipped	√	√	√	√
OPEL\2013\Adam	Engine Control Module\1.4L (LDD)\Stop/Start System (KL9)	√	√	√	√
OPEL\2013\Adam	Engine Control Module\1.2L (LWD)	√	√	√	√
OPEL\2013\Adam	Engine Control Module\1.4L (L2Z)\Not Equipped	√	√	√	√
OPEL\2013\Adam	Engine Control Module\1.4L (L2Z)\Stop/Start System (KL9)	√	√	√	√
OPEL\2013\Adam	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Adam	Body Control Module	√	√	√	√
OPEL\2013\Adam	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Adam	Instrument Cluster	√	√	√	√
OPEL\2013\Adam	Trailer Interface Control Module	√	√	√	√
OPEL\2013\Adam	Radio	√	√	√	√
OPEL\2013\Adam	HVAC Control Module	√	√	√	√
OPEL\2013\Adam	Parking Assist Control Module\Parking Assist with Front and Rear Sensors (UD5)	√	√	√	√
OPEL\2013\Adam	Parking Assist Control Module\Parking Assist with Rear Sensors (UD7)	√	√	√	√
OPEL\2013\Adam	Parking Assist Control Module\Advance Parking Assist (UDP)	√	√	√	√
OPEL\2013\Adam	Parking Assist Control Module\Advance Parking Assist with Semi Automatic Steering (UFQ)	√	√	√	√
OPEL\2013\Ampera	Engine Control Module	√	√	√	√
OPEL\2013\Ampera	Transmission Control Module	√	√	√	√
OPEL\2013\Ampera	Fuel Pump Control Module	√	√	√	√
OPEL\2013\Ampera	Hybrid Powertrain Control Module	√	√	√	√
OPEL\2013\Ampera	Hybrid Powertrain Control Module 2	√	√	√	√
OPEL\2013\Ampera	Auxiliary Transmission Fluid Pump	√	√	√	√
OPEL\2013\Ampera	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Ampera	Parking Brake Control Module	√	√	√	√
OPEL\2013\Ampera	Power Steering Control Module	√	√	√	√
OPEL\2013\Ampera	Body Control Module	√	√	√	√
OPEL\2013\Ampera	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Ampera	Instrument Cluster	√	√	√	√
OPEL\2013\Ampera	Radio	√	√	√	√
OPEL\2013\Ampera	Multimedia Player Interface Module	√	√	√	√
OPEL\2013\Ampera	Telematics Communication Interface Control Module	√	√	√	√
OPEL\2013\Ampera	HVAC Control Module	√	√	√	√
OPEL\2013\Ampera	Front Seat Heating Control Module	√	√	√	√
OPEL\2013\Ampera	Electric A/C Compressor Control Module	√			√
OPEL\2013\Ampera	Keyless Entry Control Module	√	√	√	√
OPEL\2013\Ampera	Battery Charger Control Module	√			√
OPEL\2013\Ampera	Parking Assist Control Module	√	√	√	√
OPEL\2013\Ampera	Frontview Camera Module	√	√	√	√
OPEL\2013\Ampera	Steering Column Lock Control Module	√	√	√	√
OPEL\2013\Ampera	Battery Energy Control Module	√			√
OPEL\2013\Ampera	Drive Motor Control Module 1	√	√	√	√
OPEL\2013\Ampera	Mobile Telephone Control Module	√	√	√	√
OPEL\2013\Ampera	Drive Motor Control Module 2	√	√	√	√
OPEL\2013\Ampera	Coolant Heater Control Module	√	√	√	√
OPEL\2013\Antara	Engine Control Module\2.0L (LNP)	√	√	√	√

OPEL\2013\Antara	Engine Control Module\2.2L (LNQ)	√	√	√	√
OPEL\2013\Antara	Engine Control Module\2.4L (LE9)	√	√	√	√
OPEL\2013\Antara	Engine Control Module\3.0L (LFW)	√	√	√	√
OPEL\2013\Antara	Transmission Control Module	√	√	√	√
OPEL\2013\Antara	Fuel Pump Control Module	√	√	√	
OPEL\2013\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2013\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2013\Antara	Body Control Module	√	√	√	√
OPEL\2013\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2013\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Antara	Instrument Cluster	√	√	√	√
OPEL\2013\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2013\Antara	Headlamp Control Module	√	√	√	√
OPEL\2013\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2013\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2013\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2013\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2013\Antara	Radio\DVD 100 NAVI	√	√	√	√
OPEL\2013\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2013\Antara	Radio\CDC 40 Opera	√	√	√	√
OPEL\2013\Antara	Radio\None	√	√	√	√
OPEL\2013\Antara	HVAC Control Module	√	√	√	
OPEL\2013\Antara	Remote Control Door Lock Receiver\Tire Pressure Monitoring System - Manual Learn (UJM)	√	√	√	√
OPEL\2013\Antara	Parking Assist Control Module	√	√	√	√
OPEL\2013\Antara	Mobile Telephone Control Module	√	√	√	
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.6L (LVP)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\2.0L (LHU)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.4L (LDD)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.4L (LUJ)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.6L (LDE)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.6L (LLU)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.7L (LKR)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.7L (LUD)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.7L (LUE)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\2.0L (LBS)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\2.0L (LBX)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\2.0L (LBY)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.3L (LSF)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Not Equipped\1.8L (2H0)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LVP)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\2.0L (LHU)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.4L (LDD)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.4L (LUJ)	√	√	√	√

OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LDE)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.6L (LLU)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.7L (LKR)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.7L (LUD)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.7L (LUE)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\2.0L (LBS)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\2.0L (LBX)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\2.0L (LBY)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.3L (LSF)	√	√	√	√
OPEL\2013\Astra-J	Engine Control Module\Stop/Start System (KL9)\1.8L (2H0)	√	√	√	√
OPEL\2013\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2013\Astra-J	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2013\Astra-J	Fuel Injector Control Module	√			√
OPEL\2013\Astra-J	Fuel Pump Control Module\1.6L (LVP)	√	√	√	√
OPEL\2013\Astra-J	Fuel Pump Control Module\2.0L (LHU)	√	√	√	√
OPEL\2013\Astra-J	Fuel Pump Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2013\Astra-J	Fuel Pump Control Module\1.6L (LDE)	√	√	√	√
OPEL\2013\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2013\Astra-J	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2013\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2013\Astra-J	Body Control Module	√	√	√	√
OPEL\2013\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2013\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2013\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2013\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2013\Astra-J	Radio\Radio	√	√	√	√
OPEL\2013\Astra-J	Radio\Chime (UL5)	√	√	√	
OPEL\2013\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2013\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2013\Astra-J	HVAC Control Module	√	√	√	√
OPEL\2013\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2013\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2013\Astra-J	Frontview Camera Module	√	√	√	√
OPEL\2013\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2013\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2013\Astra-J	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2013\Cascada	Engine Control Module\1.4L (LUJ)	√	√	√	√

OPEL\2013\Cascada	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2013\Cascada	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2013\Cascada	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2013\Cascada	Transmission Control Module\Transmission Control Module - AF40	√	√	√	√
OPEL\2013\Cascada	Transmission Control Module\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2013\Cascada	Fuel Pump Control Module\1.6L (LVP)	√	√	√	√
OPEL\2013\Cascada	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Cascada	Parking Brake Control Module	√	√	√	√
OPEL\2013\Cascada	Power Steering Control Module	√	√	√	√
OPEL\2013\Cascada	Body Control Module	√	√	√	√
OPEL\2013\Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Cascada	Instrument Cluster	√	√	√	√
OPEL\2013\Cascada	Headlamp Control Module	√	√	√	√
OPEL\2013\Cascada	Radio\Radio	√	√	√	√
OPEL\2013\Cascada	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2013\Cascada	Multimedia Player Interface Module	√	√	√	√
OPEL\2013\Cascada	HVAC Control Module	√	√	√	√
OPEL\2013\Cascada	Front Seat Heating Control Module	√	√	√	√
OPEL\2013\Cascada	Parking Assist Control Module	√	√	√	√
OPEL\2013\Cascada	Frontview Camera Module	√	√	√	√
OPEL\2013\Cascada	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2013\Cascada	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2013\Cascada	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2013\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2013\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2013\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2013\Combo-D	Engine Control Module\1.6L (LJ5)	√	√	√	√
OPEL\2013\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2013\Combo-D	Transmission Control Module\Automatic	√	√	√	√
OPEL\2013\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2013\Combo-D	Electronic Brake Control Module\Vehicle Stability System (FX3)	√	√	√	√
OPEL\2013\Combo-D	Body Control Module	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.8L (LBW)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\1.6L (LLU)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2013\Insignia	Engine Control Module\2.0L (LHV)	√	√	√	√
OPEL\2013\Insignia	Fuel Injector Control Module	√			√
OPEL\2013\Insignia	Fuel Pump Control Module\2.8L (LAU)	√	√	√	√
OPEL\2013\Insignia	Fuel Pump Control Module\2.8L (LBW)	√	√	√	√

OPEL\2013\Insignia	Fuel Pump Control Module\2.0L (LHU)	√	√	√	√
OPEL\2013\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2013\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2013\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2013\Insignia	Power Steering Control Module	√	√	√	√
OPEL\2013\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Insignia	Instrument Cluster	√	√	√	√
OPEL\2013\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2013\Insignia	Trailer Interface Control Module\Station Wagon	√	√	√	√
OPEL\2013\Insignia	Radio\Radio	√	√	√	√
OPEL\2013\Insignia	Radio\Chime (UL5)	√	√	√	
OPEL\2013\Insignia	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2013\Insignia	Multimedia Player Interface Module	√	√	√	√
OPEL\2013\Insignia	HVAC Control Module	√	√	√	√
OPEL\2013\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2013\Insignia	Frontview Camera Module	√	√	√	√
OPEL\2013\Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√
OPEL\2013\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2013\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2013\Insignia	Mobile Telephone Control Module	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Not Equipped\1.4L (LUJ)	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Not Equipped\1.6L (LDE)	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Not Equipped\1.7L (LUD)	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Stop/Start System (KL9)\1.4L (LUJ)	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Stop/Start System (KL9)\1.6L (LDE)	√	√	√	√
OPEL\2013\Mokka	Engine Control Module\Stop/Start System (KL9)\1.7L (LUD)	√	√	√	√
OPEL\2013\Mokka	Transmission Control Module	√	√	√	√
OPEL\2013\Mokka	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2013\Mokka	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Mokka	Power Steering Control Module	√	√	√	√
OPEL\2013\Mokka	Body Control Module	√	√	√	√
OPEL\2013\Mokka	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Mokka	Instrument Cluster	√	√	√	√
OPEL\2013\Mokka	Headlamp Control Module	√	√	√	√
OPEL\2013\Mokka	Trailer Interface Control Module	√	√	√	√
OPEL\2013\Mokka	Radio\Radio	√	√	√	√
OPEL\2013\Mokka	Radio\Chime (UL5)	√	√	√	
OPEL\2013\Mokka	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2013\Mokka	HVAC Control Module	√	√	√	√
OPEL\2013\Mokka	Front Seat Heating Control Module	√	√	√	√
OPEL\2013\Mokka	Parking Assist Control Module	√	√	√	√
OPEL\2013\Mokka	Frontview Camera Module	√	√	√	√
OPEL\2013\Mokka	Mobile Telephone Control Module	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\2.0L (LBR)	√	√	√	√

OPEL\2013\Zafira-C	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\1.6L (LVL)	√	√	√	√
OPEL\2013\Zafira-C	Engine Control Module\1.6L (LVP)	√	√	√	√
OPEL\2013\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36 MDK)	√	√	√	√
OPEL\2013\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK MHB MHC MNR)	√	√	√	√
OPEL\2013\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2013\Zafira-C	Fuel Pump Control Module\1.6L (LVP)	√	√	√	√
OPEL\2013\Zafira-C	Electronic Brake Control Module	√	√	√	√
OPEL\2013\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2013\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2013\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2013\Zafira-C	Body Control Module	√	√	√	√
OPEL\2013\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2013\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2013\Zafira-C	Headlamp Control Module	√	√	√	√
OPEL\2013\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2013\Zafira-C	Radio\Radio	√	√	√	√
OPEL\2013\Zafira-C	Radio\Chime (UL5)	√	√	√	
OPEL\2013\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2013\Zafira-C	Multimedia Player Interface Module	√	√	√	√
OPEL\2013\Zafira-C	HVAC Control Module	√	√	√	√
OPEL\2013\Zafira-C	Front Seat Heating Control Module	√	√	√	√
OPEL\2013\Zafira-C	Parking Assist Control Module	√	√	√	√
OPEL\2013\Zafira-C	Frontview Camera Module	√	√	√	√
OPEL\2013\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2013\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2013\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2012\Zafira-B	Engine-Z 16 XE1		√	√	
OPEL\2012\Zafira-B	Engine-Z 16 XEP		√	√	
OPEL\2012\Zafira-B	Engine-Z 16 XER		√	√	
OPEL\2012\Zafira-B	Engine-Z 16 YNG		√	√	
OPEL\2012\Zafira-B	Engine-A 16 XER		√	√	
OPEL\2012\Zafira-B	Engine-A 17 DTJ		√	√	
OPEL\2012\Zafira-B	Engine-A 17 DTR		√	√	
OPEL\2012\Zafira-B	Engine-Z 18 XER		√	√	
OPEL\2012\Zafira-B	Engine-A 18 XER		√	√	
OPEL\2012\Zafira-B	Engine-Z 19 DT		√	√	
OPEL\2012\Zafira-B	Engine-Z 19 DTH		√	√	
OPEL\2012\Zafira-B	Engine-Z 20 LEH		√	√	
OPEL\2012\Zafira-B	Engine-Z 20 LER		√	√	
OPEL\2012\Zafira-B	Engine-Z 22 YH		√	√	
OPEL\2012\Zafira-B	Engine-Engine(default)		√	√	
OPEL\2012\Zafira-B	Transmission-AF 40-6		√	√	
OPEL\2012\Zafira-B	Transmission-MTA(Easytronic)		√	√	
OPEL\2012\Zafira-B	Transmission-AF 22-4		√	√	
OPEL\2012\Zafira-B	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2012\Zafira-B	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	

OPEL\2012\Zafira-B	Chassis-TPMS (Tyre Pressure Monitoring System)		√	√	
OPEL\2012\Zafira-B	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2012\Zafira-B	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2012\Zafira-B	Chassis-CDC (Continuous Damping Control)		√	√	
OPEL\2012\Zafira-B	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2012\Zafira-B	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2012\Zafira-B	Body-IL (Interior Lighting)		√	√	
OPEL\2012\Zafira-B	Body-W&W (Wipers/Washer)		√	√	
OPEL\2012\Zafira-B	Body-CDL (Central Door Lock)		√	√	
OPEL\2012\Zafira-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2012\Zafira-B	Body-Immobiliser		√	√	
OPEL\2012\Zafira-B	Body-CIM (Steering Column Module)		√	√	
OPEL\2012\Zafira-B	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2012\Zafira-B	Body-EHS (Electrical Heater System)		√	√	
OPEL\2012\Zafira-B	Body-PAS (Park Pilot)		√	√	
OPEL\2012\Zafira-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Zafira-B	Body-SLM (Shift Lever Module)		√	√	
OPEL\2012\Zafira-B	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2012\Zafira-B	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2012\Zafira-B	Body-PEPS (Open&Start)		√	√	
OPEL\2012\Zafira-B	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2012\Zafira-B	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2012\Vivaro	Engine-F9Q 760/762 (1.9L)		√	√	
OPEL\2012\Vivaro	Body-PP (Park Pilot)		√	√	
OPEL\2012\Vivaro	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Vauxhall VXR8	Engine-V8 GEN IV		√	√	
OPEL\2012\Vauxhall VXR8	Transmission-Automatic Transmission		√	√	
OPEL\2012\Vauxhall VXR8	Chassis-FPCM (Fuel Pump Control Module)		√	√	
OPEL\2012\Vauxhall VXR8	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2012\Vauxhall VXR8	Chassis-ESC (Electronic Suspension Control)		√	√	
OPEL\2012\Vauxhall VXR8	Body-AHL (Automatic Headlamp Levelling)		√	√	
OPEL\2012\Vauxhall VXR8	Body-BCM (Body Control Module)		√	√	
OPEL\2012\Vauxhall VXR8	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2012\Vauxhall VXR8	Body-Immobiliser		√	√	
OPEL\2012\Vauxhall VXR8	Body-MSM (Memory Seat And Mirrors)		√	√	
OPEL\2012\Vauxhall VXR8	Body-PA (Park Assist)		√	√	
OPEL\2012\Vauxhall VXR8	Body-SDM (Sensing And Diagnostic Module)		√	√	
OPEL\2012\Vauxhall VXR8	Body-IC (Instrument Cluster)		√	√	
OPEL\2012\Vauxhall VXR8	Body-RFA (Multipurpose Receiver Module)		√	√	
OPEL\2012\Meriva-B	Engine-A 13 DTC 1.3(LDV)		√	√	
OPEL\2012\Meriva-B	Engine-A 13 DTE 1.3(LSF)		√	√	
OPEL\2012\Meriva-B	Engine-A 14 NEL (LUH)		√	√	
OPEL\2012\Meriva-B	Engine-A 14 NET (LUJ)		√	√	
OPEL\2012\Meriva-B	Engine-A 14 XER (LDD)		√	√	
OPEL\2012\Meriva-B	Engine-A 17 DTC 1.7(LUE)		√	√	
OPEL\2012\Meriva-B	Engine-A 17 DTS 1.7(LUD)		√	√	

OPEL\2012\Meriva-B	Engine-ECM (Engine Control Module)		√	√	
OPEL\2012\Meriva-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2012\Meriva-B	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2012\Meriva-B	Chassis-EPS (Electric Power Steering)		√	√	
OPEL\2012\Meriva-B	Chassis-PBCM (Parking Brake Control Module)		√	√	
OPEL\2012\Meriva-B	Chassis-SWASM (Steering Wheel Angle Sensor Module)		√	√	
OPEL\2012\Meriva-B	Body-FSHCM (Front Seat Heating Control Module)		√	√	
OPEL\2012\Meriva-B	Body-BCM (Body Control Module)		√	√	
OPEL\2012\Meriva-B	Body-HLCM (Headlamp Control Module)		√	√	
OPEL\2012\Meriva-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Meriva-B	Body-PACM (Parking Assist Control Module)		√	√	
OPEL\2012\Meriva-B	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2012\Meriva-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2012\Meriva-B	Body-TICM (Trailer Interface Control Module)		√	√	
OPEL\2012\Corsa-D	Engine-Z 10 XEP		√	√	
OPEL\2012\Corsa-D	Engine-A 10 XEP		√	√	
OPEL\2012\Corsa-D	Engine-Z 12 XEP		√	√	
OPEL\2012\Corsa-D	Engine-A 12 XEL		√	√	
OPEL\2012\Corsa-D	Engine-Z 13 DTH		√	√	
OPEL\2012\Corsa-D	Engine-Z 13 DTE		√	√	
OPEL\2012\Corsa-D	Engine-Z 13 DTJ		√	√	
OPEL\2012\Corsa-D	Engine-A 13 DTC		√	√	
OPEL\2012\Corsa-D	Engine-A 13 DTE		√	√	
OPEL\2012\Corsa-D	Engine-Z 14 XEP		√	√	
OPEL\2012\Corsa-D	Engine-A 14 XEL		√	√	
OPEL\2012\Corsa-D	Engine-A 14 XER		√	√	
OPEL\2012\Corsa-D	Engine-Z 16 LEL		√	√	
OPEL\2012\Corsa-D	Engine-Z 16 LER		√	√	
OPEL\2012\Corsa-D	Engine-A 16 LEL		√	√	
OPEL\2012\Corsa-D	Engine-A 16 LER		√	√	
OPEL\2012\Corsa-D	Engine-Z 17 DTR		√	√	
OPEL\2012\Corsa-D	Engine-Engine(default)		√	√	
OPEL\2012\Corsa-D	Transmission-MTA(Easytronic Magneti Marelli)		√	√	
OPEL\2012\Corsa-D	Transmission-AF 13-4		√	√	
OPEL\2012\Corsa-D	Transmission-MTA(Easytronic)		√	√	
OPEL\2012\Corsa-D	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2012\Corsa-D	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2012\Corsa-D	Body-XL (Exterior Lighting)		√	√	
OPEL\2012\Corsa-D	Body-IL (Interior Lighting)		√	√	
OPEL\2012\Corsa-D	Body-W&W (Wipers/Washer)		√	√	
OPEL\2012\Corsa-D	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2012\Corsa-D	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2012\Corsa-D	Body-CDL (Central Door Lock)		√	√	
OPEL\2012\Corsa-D	Body-Immobiliser		√	√	
OPEL\2012\Corsa-D	Body-AFL (Adaptive Forward Lighting)		√	√	
OPEL\2012\Corsa-D	Body-EHS (Electrical Heater System)		√	√	
OPEL\2012\Corsa-D	Body-IPC (Instrument)		√	√	
OPEL\2012\Corsa-D	Body-PAS (Park Pilot)		√	√	

OPEL\2012\Corsa-D	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Corsa-D	Body-TIM (Trailer Interface Module)		√	√	
OPEL\2012\Corsa-D	Body-BCM (Body Control Module)		√	√	
OPEL\2012\Corsa-C	Engine-Z 10 XEP		√	√	
OPEL\2012\Corsa-C	Engine-Z 12 XE		√	√	
OPEL\2012\Corsa-C	Engine-Z 12 XEP		√	√	
OPEL\2012\Corsa-C	Engine-Y 13 DT		√	√	
OPEL\2012\Corsa-C	Engine-Z 13 DT		√	√	
OPEL\2012\Corsa-C	Engine-Z 14 XE		√	√	
OPEL\2012\Corsa-C	Engine-Z 14 XEP		√	√	
OPEL\2012\Corsa-C	Engine-Z 16 SE		√	√	
OPEL\2012\Corsa-C	Engine-Z 16 YNG		√	√	
OPEL\2012\Corsa-C	Engine-Y 17 DT		√	√	
OPEL\2012\Corsa-C	Engine-Y 17 DTL		√	√	
OPEL\2012\Corsa-C	Engine-Z 17 DTH		√	√	
OPEL\2012\Corsa-C	Engine-Z 18 XE		√	√	
OPEL\2012\Corsa-C	Transmission-AF 13-II/17/20/22 CAN		√	√	
OPEL\2012\Corsa-C	Transmission-Easytronic(MTA)		√	√	
OPEL\2012\Corsa-C	Chassis-ABS8/ESP8 (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2012\Corsa-C	Chassis-ABS-5.3/5.4(+TC) (Anti-lock Braking System)		√	√	
OPEL\2012\Corsa-C	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2012\Corsa-C	Body-AOH (Add On Heater)		√	√	
OPEL\2012\Corsa-C	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Corsa-C	Body-BCM (Body Control Module)		√	√	
OPEL\2012\Corsa-C	Body-Immobiliser		√	√	
OPEL\2012\Astra-H	Engine-Z 12 XEP		√	√	
OPEL\2012\Astra-H	Engine-Y 13 DTH		√	√	
OPEL\2012\Astra-H	Engine-Z 13 DTH		√	√	
OPEL\2012\Astra-H	Engine-Z 14 XEL		√	√	
OPEL\2012\Astra-H	Engine-Z 14 XEP		√	√	
OPEL\2012\Astra-H	Engine-Z 16 LET		√	√	
OPEL\2012\Astra-H	Engine-Z 16 XE1		√	√	
OPEL\2012\Astra-H	Engine-Z 16 XEP		√	√	
OPEL\2012\Astra-H	Engine-Z 16 XER		√	√	
OPEL\2012\Astra-H	Engine-A 16 LET		√	√	
OPEL\2012\Astra-H	Engine-A 16 XER		√	√	
OPEL\2012\Astra-H	Engine-Z 17 DTH		√	√	
OPEL\2012\Astra-H	Engine-Z 17 DTJ		√	√	
OPEL\2012\Astra-H	Engine-Z 17 DTL		√	√	
OPEL\2012\Astra-H	Engine-Z 17 DTR		√	√	
OPEL\2012\Astra-H	Engine-A 17 DTJ		√	√	
OPEL\2012\Astra-H	Engine-A 17 DTR		√	√	
OPEL\2012\Astra-H	Engine-Z 18 XE		√	√	
OPEL\2012\Astra-H	Engine-Z 18 XER		√	√	
OPEL\2012\Astra-H	Engine-A 18 XER		√	√	
OPEL\2012\Astra-H	Engine-Z 19 DT		√	√	
OPEL\2012\Astra-H	Engine-Z 19 DTH		√	√	
OPEL\2012\Astra-H	Engine-Z 20 LEL		√	√	
OPEL\2012\Astra-H	Engine-Z 20 LER		√	√	
OPEL\2012\Astra-H	Engine-Z 22 YH		√	√	
OPEL\2012\Astra-H	Engine-Engine(default)		√	√	
OPEL\2012\Astra-H	Transmission-AF 40-6		√	√	
OPEL\2012\Astra-H	Transmission-AF17-4		√	√	
OPEL\2012\Astra-H	Transmission-AF 22-4		√	√	
OPEL\2012\Astra-H	Transmission-MTA(Easytronic)		√	√	
OPEL\2012\Astra-H	Transmission-MTA(Easytronic Magneti Marelli)		√	√	
OPEL\2012\Astra-H	Chassis-TPMS ECU (Tyre Pressure Monitoring)		√	√	

OPEL\2012\Astra-H	Chassis-TPMS (Tyre Pressure Monitoring System)		√	√	
OPEL\2012\Astra-H	Chassis-EHPS (Electrohydraulic Power Steering)		√	√	
OPEL\2012\Astra-H	Chassis-ABS/TC/ESP ECU (Electronic Control Unit)		√	√	
OPEL\2012\Astra-H	Chassis-CDC (Continuous Damping Control)		√	√	
OPEL\2012\Astra-H	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2012\Astra-H	Body-AHL/AFL (Headlamp Levelling)		√	√	
OPEL\2012\Astra-H	Body-XL/TIS (Exterior Lighting/Turn Indicator System)		√	√	
OPEL\2012\Astra-H	Body-IL (Interior Lighting)		√	√	
OPEL\2012\Astra-H	Body-W&W (Wipers/Washer)		√	√	
OPEL\2012\Astra-H	Body-CDL (Central Door Lock)		√	√	
OPEL\2012\Astra-H	Body-IC (Instrument Cluster)		√	√	
OPEL\2012\Astra-H	Body-Immobiliser		√	√	
OPEL\2012\Astra-H	Body-CIM (Steering Column Module)		√	√	
OPEL\2012\Astra-H	Body-ATW (Anti Theft Warning System)		√	√	
OPEL\2012\Astra-H	Body-EHHT (Electrohydraulic HardTop)		√	√	
OPEL\2012\Astra-H	Body-ECC/SAC (Electronic Climate Control)		√	√	
OPEL\2012\Astra-H	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2012\Astra-H	Body-EHS (Electrical Heater System)		√	√	
OPEL\2012\Astra-H	Body-PAS (Park Pilot)		√	√	
OPEL\2012\Astra-H	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Astra-H	Body-SLM (Shift Lever Module)		√	√	
OPEL\2012\Astra-H	Body-UEC (Underhood Electrical Centre)		√	√	
OPEL\2012\Astra-H	Body-REC (Rear Electrical Centre)		√	√	
OPEL\2012\Astra-H	Body-PEPS (Open&Start)		√	√	
OPEL\2012\Agila-B	Engine-K10B		√	√	
OPEL\2012\Agila-B	Engine-K12B		√	√	
OPEL\2012\Agila-B	Engine-D13A / Z 13 DTJ		√	√	
OPEL\2012\Agila-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2012\Agila-B	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2012\Agila-B	Body-BCM (Body Control Module)		√	√	
OPEL\2012\Agila-B	Body-Immobiliser		√	√	
OPEL\2012\Agila-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2012\Ampera	Engine Control Module	√	√	√	√
OPEL\2012\Ampera	Transmission Control Module	√	√	√	√
OPEL\2012\Ampera	Fuel Pump Control Module	√	√	√	
OPEL\2012\Ampera	Hybrid Powertrain Control Module	√	√	√	√
OPEL\2012\Ampera	Hybrid Powertrain Control Module 2	√	√	√	√
OPEL\2012\Ampera	Auxiliary Transmission Fluid Pump	√	√	√	√
OPEL\2012\Ampera	Electronic Brake Control Module	√	√	√	√
OPEL\2012\Ampera	Parking Brake Control Module	√	√	√	√
OPEL\2012\Ampera	Power Steering Control Module	√	√	√	√
OPEL\2012\Ampera	Body Control Module	√	√	√	√
OPEL\2012\Ampera	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2012\Ampera	Passenger Presence Module	√	√	√	√
OPEL\2012\Ampera	Instrument Cluster	√	√	√	√
OPEL\2012\Ampera	Radio	√	√	√	√
OPEL\2012\Ampera	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2012\Ampera	Telematics Communication Interface Control Module	√	√	√	√

OPEL\2012\Ampera	Front Seat Heating Control Module	√	√	√	√
OPEL\2012\Ampera	Electric A/C Compressor Control Module	√			√
OPEL\2012\Ampera	Keyless Entry Control Module	√	√	√	√
OPEL\2012\Ampera	Battery Charger Control Module	√			√
OPEL\2012\Ampera	Parking Assist Control Module	√	√	√	√
OPEL\2012\Ampera	Steering Column Lock Control Module	√	√	√	√
OPEL\2012\Ampera	Battery Energy Control Module	√			√
OPEL\2012\Ampera	Coolant Heater Control Module	√	√	√	√
OPEL\2012\Ampera	Mobile Telephone Control Module	√	√	√	√
OPEL\2012\Ampera	Drive Motor Control Module 2	√	√	√	√
OPEL\2012\Ampera	Drive Motor Control Module 1	√	√	√	√
OPEL\2012\Ampera	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2012\Antara	Engine Control Module\2.0L (LNP)	√	√	√	√
OPEL\2012\Antara	Engine Control Module\2.2L (LNQ)	√	√	√	√
OPEL\2012\Antara	Engine Control Module\2.4L (LE5)	√	√	√	√
OPEL\2012\Antara	Engine Control Module\2.4L (LE9)	√	√	√	√
OPEL\2012\Antara	Engine Control Module\3.0L (LF1)	√	√	√	√
OPEL\2012\Antara	Engine Control Module\3.0L (LFW)	√	√	√	√
OPEL\2012\Antara	Transmission Control Module	√	√	√	√
OPEL\2012\Antara	Fuel Pump Control Module	√	√	√	
OPEL\2012\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2012\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2012\Antara	Body Control Module	√	√	√	√
OPEL\2012\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2012\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2012\Antara	Instrument Cluster	√	√	√	√
OPEL\2012\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2012\Antara	Headlamp Control Module	√	√	√	√
OPEL\2012\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2012\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2012\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2012\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2012\Antara	Radio\DVD 100 NAVI	√	√	√	√
OPEL\2012\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2012\Antara	Radio\CDC 40 Opera	√	√	√	√
OPEL\2012\Antara	Radio\None	√	√	√	√
OPEL\2012\Antara	HVAC Control Module	√	√	√	
OPEL\2012\Antara	Remote Control Door Lock Receiver	√	√	√	√
OPEL\2012\Antara	Parking Assist Control Module	√	√	√	√
OPEL\2012\Antara	Mobile Telephone Control Module	√	√	√	
OPEL\2012\Astra-J	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\1.7L (LKR)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\1.7L (LPL)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\1.7L (LPV)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\1.7L (LUD)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\1.7L (LUE)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2012\Astra-J	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2012\Astra-J	Fuel Injector Control Module	√			√
OPEL\2012\Astra-J	Fuel Pump Control Module\2.0L (LHU)	√	√	√	
OPEL\2012\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2012\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2012\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2012\Astra-J	Body Control Module	√	√	√	√
OPEL\2012\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2012\Astra-J	Instrument Cluster	√	√	√	√

OPEL\2012\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2012\Astra-J	Trailer Interface Control Module\Equipped	√	√	√	√
OPEL\2012\Astra-J	Radio\Radio	√	√	√	√
OPEL\2012\Astra-J	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2012\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2012\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2012\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2012\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2012\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2012\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2012\Astra-J	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2012\Astra-J	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2012\Astra-J	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2012\Combo-D	Engine Control Module\1.3L (LN9)	√	√	√	√
OPEL\2012\Combo-D	Engine Control Module\1.4L (LJA)	√	√	√	√
OPEL\2012\Combo-D	Engine Control Module\1.4L (LJD)	√	√	√	√
OPEL\2012\Combo-D	Engine Control Module\1.6L (LJ5)	√	√	√	√
OPEL\2012\Combo-D	Engine Control Module\2.0L (LHZ)	√	√	√	√
OPEL\2012\Combo-D	Transmission Control Module\Automatic	√	√	√	√
OPEL\2012\Combo-D	Electronic Brake Control Module\Not Equipped	√	√	√	√
OPEL\2012\Combo-D	Body Control Module	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\1.6L (LLU)\1901	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\1.6L (LLU)\1903	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.0L (LHU)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2012\Insignia	Engine Control Module\2.8L (LBW)	√	√	√	√
OPEL\2012\Insignia	Transmission Control Module\Manual	√	√	√	√
OPEL\2012\Insignia	Fuel Pump Control Module\2.0L (LHU)	√	√	√	
OPEL\2012\Insignia	Fuel Pump Control Module\2.8L (LAU)	√	√	√	
OPEL\2012\Insignia	Fuel Pump Control Module\2.8L (LBW)	√	√	√	
OPEL\2012\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2012\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2012\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2012\Insignia	Power Steering Control Module\0211	√	√	√	√
OPEL\2012\Insignia	Power Steering Control Module\0221	√	√	√	√
OPEL\2012\Insignia	Power Steering Control Module\0301	√	√	√	√
OPEL\2012\Insignia	Power Steering Control Module\other	√	√	√	√
OPEL\2012\Insignia	Body Control Module	√	√	√	√
OPEL\2012\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2012\Insignia	Instrument Cluster	√	√	√	√
OPEL\2012\Insignia	Headlamp Control Module	√	√	√	√

OPEL\2012\Insignia	Trailer Interface Control Module\Equipped	√	√	√	√
OPEL\2012\Insignia	Trailer Interface Control Module\Not Equipped	√	√	√	√
OPEL\2012\Insignia	Radio\Radio	√	√	√	√
OPEL\2012\Insignia	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2012\Insignia	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2012\Insignia	Multimedia Player Interface Module	√	√	√	√
OPEL\2012\Insignia	Seat Memory Control Module	√	√	√	√
OPEL\2012\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2012\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2012\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2012\Insignia	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2012\Insignia	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2012\Insignia	Mobile Telephone Control Module	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\1.4L (LUJ)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\1.6L (LGE)	√	√	√	√
OPEL\2012\Zafira-C	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2012\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 Gen II (MDK)	√	√	√	√
OPEL\2012\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - AF40 (M36)	√	√	√	√
OPEL\2012\Zafira-C	Transmission Control Module\Automatic\Transmission Control Module - T76 (MH7 MH8 MH9 MHH MHJ MHK)	√	√	√	√
OPEL\2012\Zafira-C	Fuel Injector Control Module	√			√
OPEL\2012\Zafira-C	Parking Brake Control Module	√	√	√	√
OPEL\2012\Zafira-C	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2012\Zafira-C	Power Steering Control Module	√	√	√	√
OPEL\2012\Zafira-C	Body Control Module	√	√	√	√
OPEL\2012\Zafira-C	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2012\Zafira-C	Instrument Cluster	√	√	√	√
OPEL\2012\Zafira-C	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2012\Zafira-C	Trailer Interface Control Module	√	√	√	√
OPEL\2012\Zafira-C	Radio\Radio	√	√	√	√
OPEL\2012\Zafira-C	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2012\Zafira-C	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2012\Zafira-C	Multimedia Player Interface Module	√	√	√	√
OPEL\2012\Zafira-C	Front Seat Heating Control Module	√	√	√	√
OPEL\2012\Zafira-C	Parking Assist Control Module	√	√	√	√
OPEL\2012\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2012\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2012\Zafira-C	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√

OPEL\2012\Zafira-C	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2012\Zafira-C	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2011\Vivaro	Engine-F9Q 760/762 (1.9L)		√	√	
OPEL\2011\Vivaro	Body-PP (Park Pilot)		√	√	
OPEL\2011\Vivaro	Body-AOH (Add On Heater)		√	√	
OPEL\2011\Vivaro	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2011\Vauxhall VXR8	Engine-V8 GEN IV		√	√	
OPEL\2011\Vauxhall VXR8	Transmission-Automatic Transmission		√	√	
OPEL\2011\Vauxhall VXR8	Chassis-FPCM (Fuel Pump Control Module)		√	√	
OPEL\2011\Vauxhall VXR8	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2011\Vauxhall VXR8	Chassis-ESC (Electronic Suspension Control)		√	√	
OPEL\2011\Vauxhall VXR8	Body-AHL (Automatic Headlamp Levelling)		√	√	
OPEL\2011\Vauxhall VXR8	Body-BCM (Body Control Module)		√	√	
OPEL\2011\Vauxhall VXR8	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2011\Vauxhall VXR8	Body-Immobiliser		√	√	
OPEL\2011\Vauxhall VXR8	Body-MSM (Memory Seat And Mirrors)		√	√	
OPEL\2011\Vauxhall VXR8	Body-PA (Park Assist)		√	√	
OPEL\2011\Vauxhall VXR8	Body-SDM (Sensing And Diagnostic Module)		√	√	
OPEL\2011\Vauxhall VXR8	Body-IC (Instrument Cluster)		√	√	
OPEL\2011\Vauxhall VXR8	Body-RFA (Multipurpose Receiver Module)		√	√	
OPEL\2011\Meriva-B	Engine-A 13 DTC 1.3(LDV)		√	√	
OPEL\2011\Meriva-B	Engine-A 13 DTE 1.3(LSF)		√	√	
OPEL\2011\Meriva-B	Engine-A 14 NET (LUJ)		√	√	
OPEL\2011\Meriva-B	Engine-A 14 XER (LDD)		√	√	
OPEL\2011\Meriva-B	Engine-A 17 DTC 1.7(LUE)		√	√	
OPEL\2011\Meriva-B	Engine-A 17 DTS 1.7(LUD)		√	√	
OPEL\2011\Meriva-B	Engine-ECM (Engine Control Module)		√	√	
OPEL\2011\Meriva-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2011\Meriva-B	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2011\Meriva-B	Chassis-EPS (Electric Power Steering)		√	√	
OPEL\2011\Meriva-B	Chassis-PBCM (Parking Brake Control Module)		√	√	
OPEL\2011\Meriva-B	Chassis-SWASM (Steering Wheel Angle Sensor Module)		√	√	
OPEL\2011\Meriva-B	Body-FSHCM (Front Seat Heating Control Module)		√	√	
OPEL\2011\Meriva-B	Body-BCM (Body Control Module)		√	√	
OPEL\2011\Meriva-B	Body-HLCM (Headlamp Control Module)		√	√	
OPEL\2011\Meriva-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2011\Meriva-B	Body-PACM (Parking Assist Control Module)		√	√	
OPEL\2011\Meriva-B	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2011\Meriva-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2011\Meriva-B	Body-TICM (Trailer Interface Control Module)		√	√	
OPEL\2011\Captiva(Long Body)	Transmission-TCCM (Transfer Case Control Module)		√	√	

OPEL\2011\Captiva(Long Body)	Transmission-Automatic Transmission		√	√	
OPEL\2011\Captiva(Long Body)	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2011\Captiva(Long Body)	Chassis-FPCM (Fuel Pump Control Module)		√	√	
OPEL\2011\Captiva(Long Body)	Body-BCM (Body Control Module)		√	√	
OPEL\2011\Captiva(Long Body)	Body-ECC (Electronic Climate Control)		√	√	
OPEL\2011\Captiva(Long Body)	Body-Immobiliser		√	√	
OPEL\2011\Captiva(Long Body)	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2011\Captiva(Long Body)	Body-PAS (Park Pilot)		√	√	
OPEL\2011\Captiva(Long Body)	Body-XBCM (Auxiliary Body Control Module)		√	√	
OPEL\2011\Captiva(Long Body)	Body-RFA (Multipurpose Receiver Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Engine-2.2L(LNQ)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Engine-2.4L(LE9)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Transmission-TCCM (Transfer Case Control Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Transmission-Automatic Transmission		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Chassis-FPCM (Fuel Pump Control Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Chassis-PBCM (Parking Brake Control Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-AHL (Automatic Headlamp Levelling)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-BCM (Body Control Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-ECC (Electronic Climate Control)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-PAS (Park Pilot)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-XBCM (Auxiliary Body Control Module)		√	√	
OPEL\2011\Antara,Captiva(Short Body)	Body-RFA (Multipurpose Receiver Module)		√	√	
OPEL\2011\Agila-B	Engine-K10B		√	√	
OPEL\2011\Agila-B	Engine-K12B		√	√	
OPEL\2011\Agila-B	Engine-D13A / Z 13 DTJ		√	√	
OPEL\2011\Agila-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2011\Agila-B	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2011\Agila-B	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2011\Agila-B	Body-BCM (Body Control Module)		√	√	
OPEL\2011\Agila-B	Body-Immobiliser		√	√	
OPEL\2011\Agila-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2011\Antara	Engine Control Module\2.2L (LNQ)	√	√	√	√
OPEL\2011\Antara	Engine Control Module\2.4L (LE5)	√	√	√	√
OPEL\2011\Antara	Engine Control Module\3.0L (LF1)	√	√	√	√
OPEL\2011\Antara	Transmission Control Module\2.2L (LNQ)	√	√	√	√
OPEL\2011\Antara	Transmission Control Module\2.4L (LE5)	√	√	√	√
OPEL\2011\Antara	Transmission Control Module\3.0L (LF1)	√	√	√	√

OPEL\2011\Antara	Fuel Pump Control Module\2.4L (LE5)	√	√	√	
OPEL\2011\Antara	Fuel Pump Control Module\3.0L (LF1)	√	√	√	
OPEL\2011\Antara	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2011\Antara	Electronic Brake Control Module	√	√	√	√
OPEL\2011\Antara	Parking Brake Control Module	√	√	√	√
OPEL\2011\Antara	Body Control Module	√	√	√	√
OPEL\2011\Antara	Auxiliary Body Control Module	√	√	√	√
OPEL\2011\Antara	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2011\Antara	Instrument Cluster	√	√	√	√
OPEL\2011\Antara	Theft Deterrent Module	√	√	√	√
OPEL\2011\Antara	Headlamp Control Module	√	√	√	√
OPEL\2011\Antara	Radio\CD 30 MP3	√	√	√	√
OPEL\2011\Antara	Radio\CD 30 MP3 DMB	√	√	√	√
OPEL\2011\Antara	Radio\CD 40 USB	√	√	√	√
OPEL\2011\Antara	Radio\CD 40 USB DMB	√	√	√	√
OPEL\2011\Antara	Radio\DVD 100 NAVI	√	√	√	√
OPEL\2011\Antara	Radio\Touch & Connect	√	√	√	√
OPEL\2011\Antara	Radio\CDC 40 Opera	√	√	√	√
OPEL\2011\Antara	Radio\None	√	√	√	√
OPEL\2011\Antara	HVAC Control Module	√	√	√	
OPEL\2011\Antara	Parking Assist Control Module	√	√	√	
OPEL\2011\Antara	Mobile Telephone Control Module	√	√	√	√
OPEL\2011\Antara	Info Display Module	√	√	√	
OPEL\2011\Astra-J	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2011\Astra-J	Engine Control Module\1.7L (LPL)	√	√	√	√
OPEL\2011\Astra-J	Engine Control Module\1.7L (LPV)	√	√	√	√
OPEL\2011\Astra-J	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2011\Astra-J	Fuel Pump Control Module\1.4L (LDD)	√	√	√	
OPEL\2011\Astra-J	Fuel Pump Control Module\1.4L (LUJ)	√	√	√	
OPEL\2011\Astra-J	Fuel Pump Control Module\1.6L (LDE)	√	√	√	
OPEL\2011\Astra-J	Electronic Brake Control Module	√	√	√	√
OPEL\2011\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2011\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2011\Astra-J	Body Control Module	√	√	√	√
OPEL\2011\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2011\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2011\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2011\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2011\Astra-J	Trailer Interface Control Module\Equipped	√	√	√	√
OPEL\2011\Astra-J	Radio\Radio	√	√	√	√
OPEL\2011\Astra-J	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2011\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2011\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2011\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2011\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2011\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2011\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2011\Astra-J	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2011\Astra-J	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2011\Astra-J	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\1.6L (LDE)	√	√	√	√

OPEL\2011\Insignia	Engine Control Module\1.6L (LLU)\1901	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\1.6L (LLU)\1903	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.0L (LBQ)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.0L (LBR)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.0L (LDK)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2011\Insignia	Engine Control Module\2.8L (LBW)	√	√	√	√
OPEL\2011\Insignia	Transmission Control Module\Manual	√	√	√	√
OPEL\2011\Insignia	Fuel Pump Control Module\2.0L (LDK)	√	√	√	
OPEL\2011\Insignia	Fuel Pump Control Module\2.0L (LHU)	√	√	√	
OPEL\2011\Insignia	Fuel Pump Control Module\2.8L (LAU)	√	√	√	
OPEL\2011\Insignia	Fuel Pump Control Module\2.8L (LBW)	√	√	√	
OPEL\2011\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2011\Insignia	Electronic Brake Control Module	√	√	√	√
OPEL\2011\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2011\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2011\Insignia	Power Steering Control Module\0211	√	√	√	√
OPEL\2011\Insignia	Power Steering Control Module\0221	√	√	√	√
OPEL\2011\Insignia	Power Steering Control Module\0301	√	√	√	√
OPEL\2011\Insignia	Power Steering Control Module\other	√	√	√	√
OPEL\2011\Insignia	Body Control Module	√	√	√	√
OPEL\2011\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2011\Insignia	Instrument Cluster	√	√	√	√
OPEL\2011\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2011\Insignia	Trailer Interface Control Module\Station Wagon\Equipped	√	√	√	√
OPEL\2011\Insignia	Trailer Interface Control Module\Station Wagon\Not Equipped	√	√	√	√
OPEL\2011\Insignia	Radio\Radio	√	√	√	√
OPEL\2011\Insignia	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2011\Insignia	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2011\Insignia	Multimedia Player Interface Module	√	√	√	√
OPEL\2011\Insignia	Seat Memory Control Module	√	√	√	√
OPEL\2011\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2011\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2011\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2011\Insignia	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2011\Insignia	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2011\Insignia	Mobile Telephone Control Module	√	√	√	√
OPEL\2010\Movano	Chassis-ABS/ESP (Anti-lock Braking System)\Electronic Stabilit		√	√	
OPEL\2010\Movano	Body-BCM (Body Control Module)		√	√	
OPEL\2010\Movano	Body-PP (Park Pilot)		√	√	
OPEL\2010\Meriva-B	Engine-A 13 DTC 1.3(LDV)		√	√	
OPEL\2010\Meriva-B	Engine-A 13 DTE 1.3(LSF)		√	√	
OPEL\2010\Meriva-B	Engine-A 14 NEL (LUH)		√	√	
OPEL\2010\Meriva-B	Engine-A 14 NET (LUJ)		√	√	
OPEL\2010\Meriva-B	Engine-A 17 DTC 1.7(LUE)		√	√	
OPEL\2010\Meriva-B	Engine-A 17 DTS 1.7(LUD)		√	√	

OPEL\2010\Meriva-B	Engine-ECM (Engine Control Module)		√	√	
OPEL\2010\Meriva-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2010\Meriva-B	Chassis-EBCM (Electronic Brake Control Module)		√	√	
OPEL\2010\Meriva-B	Chassis-EPS (Electric Power Steering)		√	√	
OPEL\2010\Meriva-B	Chassis-PBCM (Parking Brake Control Module)		√	√	
OPEL\2010\Meriva-B	Chassis-SWASM (Steering Wheel Angle Sensor Module)		√	√	
OPEL\2010\Meriva-B	Body-FSHCM (Front Seat Heating Control Module)		√	√	
OPEL\2010\Meriva-B	Body-BCM (Body Control Module)		√	√	
OPEL\2010\Meriva-B	Body-HLCM (Headlamp Control Module)		√	√	
OPEL\2010\Meriva-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2010\Meriva-B	Body-PACM (Parking Assist Control Module)		√	√	
OPEL\2010\Meriva-B	Body-HVAC (Heating Ventilation Air-conditioning and Cooling)		√	√	
OPEL\2010\Meriva-B	Body-IC (Instrument Cluster)		√	√	
OPEL\2010\Meriva-B	Body-TICM (Trailer Interface Control Module)		√	√	
OPEL\2010\Captiva(Long Body)	Engine-2.0 L (Diesel)		√	√	
OPEL\2010\Captiva(Long Body)	Engine-Z 32 SE		√	√	
OPEL\2010\Captiva(Long Body)	Transmission-TCCM (Transfer Case Control Module)		√	√	
OPEL\2010\Captiva(Long Body)	Transmission-Automatic Transmission		√	√	
OPEL\2010\Captiva(Long Body)	Chassis-ABS/TC/ESP (Vehicle Dynamic System)		√	√	
OPEL\2010\Captiva(Long Body)	Body-BCM (Body Control Module)		√	√	
OPEL\2010\Captiva(Long Body)	Body-ECC (Electronic Climate Control)		√	√	
OPEL\2010\Captiva(Long Body)	Body-Immobiliser		√	√	
OPEL\2010\Captiva(Long Body)	Body-IPC ECU (Instrument Control Unit)		√	√	
OPEL\2010\Captiva(Long Body)	Body-XBCM (Auxiliary Body Control Module)		√	√	
OPEL\2010\Captiva(Long Body)	Body-RFA (Multipurpose Receiver Module)		√	√	
OPEL\2010\Agila-B	Engine-K10B		√	√	
OPEL\2010\Agila-B	Engine-K12B		√	√	
OPEL\2010\Agila-B	Engine-D13A / Z 13 DTJ		√	√	
OPEL\2010\Agila-B	Transmission-TCM (Transmission Control Module)		√	√	
OPEL\2010\Agila-B	Chassis-ABS/ESP (Anti-lock Braking System/Electronic Stabilit		√	√	
OPEL\2010\Agila-B	Chassis-EPS (Electronic Power Steering)		√	√	
OPEL\2010\Agila-B	Body-BCM (Body Control Module)		√	√	
OPEL\2010\Agila-B	Body-Immobiliser		√	√	
OPEL\2010\Agila-B	Body-SRS (Supplemental Inflatable Restraint System)		√	√	
OPEL\2010\Astra-J	Engine Control Module\1.3L (LSF)	√	√	√	√
OPEL\2010\Astra-J	Engine Control Module\1.7L (LPL)	√	√	√	√
OPEL\2010\Astra-J	Engine Control Module\1.7L (LPV)	√	√	√	√
OPEL\2010\Astra-J	Fuel Pump Control Module\1.4L (LDD)	√	√	√	
OPEL\2010\Astra-J	Fuel Pump Control Module\1.4L (LUJ)	√	√	√	
OPEL\2010\Astra-J	Fuel Pump Control Module\1.6L (LDE)	√	√	√	
OPEL\2010\Astra-J	Electronic Brake Control Module	√	√	√	√

OPEL\2010\Astra-J	Parking Brake Control Module	√	√	√	√
OPEL\2010\Astra-J	Power Steering Control Module	√	√	√	√
OPEL\2010\Astra-J	Body Control Module	√	√	√	√
OPEL\2010\Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2010\Astra-J	Instrument Cluster	√	√	√	√
OPEL\2010\Astra-J	Headlamp Control Module\Automotive Lighting	√	√	√	√
OPEL\2010\Astra-J	Headlamp Control Module\Hella	√	√	√	√
OPEL\2010\Astra-J	Trailer Interface Control Module	√	√	√	√
OPEL\2010\Astra-J	Radio\Radio	√	√	√	√
OPEL\2010\Astra-J	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2010\Astra-J	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2010\Astra-J	Multimedia Player Interface Module	√	√	√	√
OPEL\2010\Astra-J	Front Seat Heating Control Module	√	√	√	√
OPEL\2010\Astra-J	Parking Assist Control Module	√	√	√	√
OPEL\2010\Astra-J	Mobile Telephone Control Module\Bluetooth (UPH)	√	√	√	√
OPEL\2010\Astra-J	Mobile Telephone Control Module\Bluetooth (UPI)	√	√	√	√
OPEL\2010\Astra-J	Mobile Telephone Control Module\Bluetooth (UPJ)	√	√	√	√
OPEL\2010\Astra-J	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2010\Astra-J	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\1.6L (LLU)\1901	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\1.6L (LLU)\1903	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.0L (LCD)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.0L (LDK)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2010\Insignia	Engine Control Module\2.8L (LBW)	√	√	√	√
OPEL\2010\Insignia	Transmission Control Module\Manual	√	√	√	√
OPEL\2010\Insignia	Fuel Pump Control Module\2.0L (LDK)	√	√	√	
OPEL\2010\Insignia	Fuel Pump Control Module\2.8L (LAU)	√	√	√	
OPEL\2010\Insignia	Fuel Pump Control Module\2.8L (LBW)	√	√	√	
OPEL\2010\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2010\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2010\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2010\Insignia	Power Steering Control Module\0211	√	√	√	√
OPEL\2010\Insignia	Power Steering Control Module\0221	√	√	√	√
OPEL\2010\Insignia	Power Steering Control Module\0301	√	√	√	√
OPEL\2010\Insignia	Power Steering Control Module\other	√	√	√	√
OPEL\2010\Insignia	Body Control Module	√	√	√	√
OPEL\2010\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2010\Insignia	Instrument Cluster	√	√	√	√
OPEL\2010\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2010\Insignia	Trailer Interface Control Module\Station Wagon\Equipped	√	√	√	√
OPEL\2010\Insignia	Trailer Interface Control Module\Station Wagon\Not Equipped	√	√	√	√
OPEL\2010\Insignia	Radio\Radio	√	√	√	√

OPEL\2010\Insignia	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2010\Insignia	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2010\Insignia	Multimedia Player Interface Module	√	√	√	√
OPEL\2010\Insignia	Seat Memory Control Module	√	√	√	√
OPEL\2010\Insignia	Front Seat Heating Control Module	√	√	√	√
OPEL\2010\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2010\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2010\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2010\Insignia	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2010\Insignia	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2010\Insignia	Mobile Telephone Control Module	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\1.6L (LDE)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\1.6L (LLU)\1901	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\1.6L (LLU)\1903	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\1.8L (2H0)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.0L (LBS)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.0L (LBX)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.0L (LBY)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.0L (LCD)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.0L (LDK)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.8L (LAU)	√	√	√	√
OPEL\2009\Insignia	Engine Control Module\2.8L (LBW)	√	√	√	√
OPEL\2009\Insignia	Transmission Control Module\Manual	√	√	√	√
OPEL\2009\Insignia	Fuel Pump Control Module\2.0L (LDK)	√	√	√	
OPEL\2009\Insignia	Fuel Pump Control Module\2.8L (LBW)	√	√	√	
OPEL\2009\Insignia	Rear Differential Clutch Control Module	√	√	√	√
OPEL\2009\Insignia	Parking Brake Control Module	√	√	√	√
OPEL\2009\Insignia	Distance Sensing Cruise Control Module	√	√	√	√
OPEL\2009\Insignia	Power Steering Control Module\0211	√	√	√	√
OPEL\2009\Insignia	Power Steering Control Module\0221	√	√	√	√
OPEL\2009\Insignia	Power Steering Control Module\0301	√	√	√	√
OPEL\2009\Insignia	Power Steering Control Module\other	√	√	√	√
OPEL\2009\Insignia	Body Control Module	√	√	√	√
OPEL\2009\Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√
OPEL\2009\Insignia	Instrument Cluster	√	√	√	√
OPEL\2009\Insignia	Headlamp Control Module	√	√	√	√
OPEL\2009\Insignia	Trailer Interface Control Module\Station Wagon\Equipped	√	√	√	√
OPEL\2009\Insignia	Trailer Interface Control Module\Station Wagon\Not Equipped	√	√	√	√
OPEL\2009\Insignia	Radio\Radio	√	√	√	√
OPEL\2009\Insignia	Chime Alarm Control Module\Chime	√	√	√	
OPEL\2009\Insignia	Digital Radio Receiver Control Module	√	√	√	√
OPEL\2009\Insignia	Multimedia Player Interface Module	√	√	√	√
OPEL\2009\Insignia	Seat Memory Control Module	√	√	√	√
OPEL\2009\Insignia	Parking Assist Control Module	√	√	√	√
OPEL\2009\Insignia	Liftgate Control Module\Mechanical	√	√	√	√
OPEL\2009\Insignia	Liftgate Control Module\Power Liftgate (TB5)	√	√	√	√
OPEL\2009\Insignia	Remote Heater and Air Conditioning Control Module	√	√	√	√
OPEL\2009\Insignia	Vehicle Direction Camera Control Module	√	√	√	√
OPEL\2009\Insignia	Mobile Telephone Control Module	√	√	√	√

Vehicle models covered					
Region	Model	Year			
EUROPE	Adam	2013 - 2017			
EUROPE	Ampera-e	2017 - 2017			
EUROPE	Antara	2011 - 2017			
EUROPE	Astra-J	2010 - 2017			
EUROPE	Astra-K	2016 - 2017			
EUROPE	Cascada	2013 - 2017			
EUROPE	Combo-D	2012 - 2017			
EUROPE	Corsa-E	2015 - 2017			
EUROPE	Insignia	2009 - 2017			
EUROPE	Karl / Viva	2016 - 2017			
EUROPE	Mokka	2013 - 2017			
EUROPE	Movano-B	2015 - 2017			
EUROPE	Vivaro-B	2015 - 2017			
EUROPE	Zafira-C	2012 - 2017			
EUROPE	Ampera	2012 - 2015			
EUROPE	Astra-H	2004 - 2014			
EUROPE	Corsa-D	2007 - 2014			
EUROPE	Zafira-B	2005 - 2014			
EUROPE	Vivaro	2001 - 2013			
EUROPE	Agila-B	2010 - 2013			
EUROPE	Vauxhall VXR8	2011 - 2012			
EUROPE	Corsa-C	2001 - 2012			
EUROPE	Captiva(Long Body)	2010 - 2011			
EUROPE	Body)	2008 - 2011			
EUROPE	Astra-G	1998 - 2011			
EUROPE	Movano	2010 - 2010			
EUROPE	Meriva	2003 - 2010			
EUROPE	Tigra-B	2005 - 2009			
EUROPE	Vectra-C/Signum	2002 - 2008			
EUROPE	Agila	2000 - 2007			
EUROPE	Speedster/VX220	2001 - 2007			
EUROPE	Zafira	1999 - 2005			
EUROPE	Corsa-B	1997 - 2003			
EUROPE	Omega-B	1997 - 2003			
EUROPE	Frontera-B	1999 - 2003			
EUROPE	Astra-F	1997 - 2002			
EUROPE	Vectra-B	1997 - 2001			
EUROPE	Tigra	1997 - 2000			
EUROPE	Monterey	1997 - 1999			
EUROPE	Sintra	1997 - 1999			
EUROPE	Frontera	1997 - 1998			
EUROPE	Calibra	1997 - 1997			
BRAZIL	Astra-G	1999 - 2009			
BRAZIL	Celta	2000 - 2009			
BRAZIL	Corsa-B	1999 - 2009			
BRAZIL	Corsa-C	2002 - 2009			
BRAZIL	E-Lux	2006 - 2009			
BRAZIL	Meriva	2003 - 2009			
BRAZIL	S-10 Truck/Blaze	1999 - 2009			
BRAZIL	Tigra	1998 - 2000			
BRAZIL	Tracker	2001 - 2009			
BRAZIL	Vectra-B	1998 - 2005			
BRAZIL	Zafira	2001 - 2009			

Vehicle Special Function covered		
System	Type	Special Function
Body	Airbag	Clear Deployment Record
Body	Anti Theft Warning	Erase Key Set
Body	Anti Theft Warning	Program Transponder-Keys
Body	BCM	Erase Key And Remote
Body	BCM	Program Key And Remote

Body	BCM(Body Control	Erase Key And Remote
Body	BCM(Body Control	Program Key And Remote
Body	Body Control Module	ECU Control
Body	Body Control Module	Erase Remote Keys
Body	Body Control Module	Program Remote Key
Body	CIM	Erase Remote Key
Body	CIM	Program Remote Key
Body	CIM (Steering Column Module)	Erase Transponder-Keys And Remote
Body	CIM (Steering Column Module)	Program Transponder-Keys And Remote
Body	CIM(Steering Column	Erase Transponder-Keys And Remote
Body	CIM(Steering Column	Program Transponder-Keys And Remote
Body	EHS	Reset ECU
Body	EHS(Electrical Heater System)	Reset ECU
Body	HeadLampLevelling	Calibration
Body	Immobiliser	Erase Key Set
Body	Immobiliser	Erase Key Set;
Body	Immobiliser	Program Transponder-Keys
Body	Instrument	Service Due In
Body	Instrument	Service Light Reset
Body Control Module	BCM	Brake Pedal Position Sensor
Body Control Module	BCM	Clear Driver Window Learn
Body Control Module	BCM	Clear Passenger Window Learn Values
Body Control Module	BCM	Clear Right Rear Window Learn Values
Chassis	ABS8/ESP8	Steering Angle Sensor
Chassis	Electronic Power Steering	Steering angle calibration
Electric Power Steering Control Module	EPSCM	Power Steering Softstops Learn
Electric Power Steering Control Module	EPSCM	Power Steering Softstops Reset
Electric Power Steering Control Module	EPSCM	Power Steering Softstops Learn
Electric Power Steering Control Module	EPSCM	Power Steering Softstops Reset
Electronic Brake Control Module	EBCM	Brake Pedal Position Sensor Calibration
Electronic Brake Control Module	EBCM	Brake Pressure Sensor
Electronic Brake Control Module	EBCM	Steering Wheel Angle Sensor
Electronic Brake Control Module	EBCM	Steering Wheel Angle Sensor Learns
Electronic Brake Control Module	EBCM	Yaw Rate Sensor Learn
Engine	2.0L	Program High
Engine	2.0L	Regeneration DPF
Engine	2.0L	Replace Diff.-Press. Sensor
Engine	2.0L	Replace Rail Pressure Sensor
Engine	C 20 SEL	Adjust Idle Speed
Engine	C 22 SEL	Adjust Idle Speed
Engine	X 16 XEL	Adjust Idle Speed
Engine	X 18 XE	Adjust Idle Speed
Engine	X 18 XE1	Adjust Idle Speed
Engine	X 20 XEV	Adjust Idle Speed
Engine	Y 20 DTH	Adjust Idle Speed
Engine	Y 22 DTR	Adjust Idle Speed
Engine	Z 13 DT	Inject Cutoff Test;
Engine	Z 13 DT	Injector Cutoff Test;
Engine	Z 13 DT	Program Idle Speed.
Engine	Z 13 DT	RPM Control;
Engine	Z 13 DTH	ECU Control(Injector cutoff test)
Engine	Z 13 DTH	ECU Reset
Engine	Z 13 DTH	Program High

Engine	Z 13 DTH	Program Injector
Engine	Z 13 DTJ	ECU Control(Injector cutoff test)
Engine	Z 13 DTJ	ECU Reset
Engine	Z 13 DTJ	Program High
Engine	Z 14 XEP	ECU Control-Electronic throttle control
Engine	Z 14 XEP	ECU Reset
Engine	Z 14 XEP	Idle speed program
Engine	Z 14 XEP	Idle speed program.
Engine	Z 14 XEP	Reset Learn Values
Engine	Z 14 XEP	Reset Learned Values;
Engine	Z 14 XEP	Reset O2-Loop Block Lean Map
Engine	Z 14 XEP	Reset O2-Loop Block Learn
Engine	Z 16 XER	Injector Cutoff Test
Engine	Z 17 DTH	EGR Control;
Engine	Z 17 DTH	Inject Cutoff Test;
Engine	Z 17 DTH	Injector Cutoff Test;
Engine	Z 17 DTH	RPM Control;
Engine	Z 17 DTH	Replace Fuel Pump.
Engine	Z 17 DTR	Program High
Engine	Z 17 DTR	Regeneration DPF
Engine	Z 17 DTR	Replace DPF
Engine	Z 17 DTR	Replace Diff.-Press. Sensor
Engine	Z 17 DTR	Replace MAF Sensor
Engine	Z 17 DTR	Replace Precatalyst
Engine	Z 17 DTR	Replace Rail Pressure Sensor
Engine	Z 17DTH	Program High Speed CAN-Bus Configuration
Engine	Z 17DTH	Replace Injector
Engine	Z 17DTH	Replace Rail Pressure Sensor
Engine	Z 17DTH	Reset ECU
Engine	Z 18 XE	Injector Cutoff Test
Engine	Z 18 XER	Injector Cutoff Test
Engine	Z 19 DT	Program High Speed CAN-Bus Configuration
Engine	Z 19 DT	Program Idle Speed
Engine	Z 19 DT	Program Injector
Engine	Z 19 DT	Regeneration D. Particulate
Engine	Z 19 DT	Regeneration Diesel Particulate Filter
Engine	Z 19 DT	Replace O2 Sensor
Engine	Z 19 DT	Replace Diesel Particulate Filter
Engine	Z 19 DT	Replace Disel Particulate Filter
Engine	Z 19 DT	Replace Injector
Engine	Z 19 DT	Replace Mass air flow sensor
Engine	Z 19 DT	Replace Precatalyst
Engine	Z 19 DT	Replace Rail Progressure
Engine	Z 19 DT	Reset ECU
Engine	Z 19 DT	Reset Engine Oil Life
Engine	Z 19 DTH	DPF Regeneration
Engine	Z 19 DTH	Idle Speed
Engine	Z 19 DTH	Program High Speed CAN-Bus Configuration
Engine	Z 19 DTH	Program High Speed Can Bus Config.
Engine	Z 19 DTH	Program Idle Speed
Engine	Z 19 DTH	Program Injector
Engine	Z 19 DTH	Regeneration D. Particulate
Engine	Z 19 DTH	Regeneration Diesel Particulate Filter
Engine	Z 19 DTH	Replace O2 Sensor
Engine	Z 19 DTH	Replace O3 Sensor
Engine	Z 19 DTH	Replace DPF
Engine	Z 19 DTH	Replace Diesel Particulate Filter
Engine	Z 19 DTH	Replace Disel Particulate Filter

Engine	Z 19 DTH	Replace Injector
Engine	Z 19 DTH	Replace Mass air flow sensor
Engine	Z 19 DTH	Replace O2 sensor
Engine	Z 19 DTH	Replace Precatalyst
Engine	Z 19 DTH	Replace Rail Pressure sensor
Engine	Z 19 DTH	Replace Rail Progressure
Engine	Z 19 DTH	Replace Rail
Engine	Z 19 DTH	Reset ECU
Engine	Z 19 DTH	Reset Engine Oil Life
Engine	Z 19 DTH	Reset O2 sensor
Engine	Z 19 DTH	Reset engine oil sensor
Engine	Z 20 NET	Reset Oil Life
Engine	Z 22 SE	ECU Control
Engine	Z 22 SE	Programming
Engine	Z 22 XE	EGR Control
Engine	Z 22 XE	Electronic Throttle Control
Engine	Z 22 XE	Fuel Tank Ventilation Control
Engine	Z 22 XE	Injector Cutoff Test
Engine	Z 22 XE	RPM Control
Engine	Z 22 YH	Injector Cutoff Test
Engine	Z13DTH	ECU Control
Engine	Z13DTH	Program High Speed CAN-Bus Configuration
Engine	Z13DTH	Program Injector
Engine	Z13DTH	Reset ECU
Engine	Z13DTJ	Injector CutOff Test
Engine	Z13DTJ	Program Idle Speed
Engine	Z13DTJ	RPM Control
Engine	Z14XEL	ECU Control
Engine	Z14XEL	Program High Speed CAN-Bus Configuration
Engine	Z14XEL	Program Idle Speed
Engine	Z14XEL	Reset ECU
Engine	Z14XEL	Reset O2-Loop Block Learn
Engine	Z14XEP	ECU Control
Engine	Z14XEP	Program High Speed CAN-Bus Configuration
Engine	Z14XEP	Program Idle Speed
Engine	Z14XEP	Reset ECU
Engine	Z14XEP	Reset O2-Loop Block Learn
Engine	Z16XEP	ECU Control
Engine	Z16XEP	Electronic Throttle Control
Engine	Z16XEP	Injector Cut off Test
Engine	Z16XEP	Program High Can
Engine	Z16XEP	Program High Speed CAN-Bus Configuration
Engine	Z16XEP	Program Idle Speed
Engine	Z16XEP	Reset ECU
Engine	Z16XEP	Reset Learn Values
Engine	Z16XEP	Reset O2-Loop Block Learn
Engine	Z16XER	ECU Control
Engine	Z16XER	Program High Speed CAN-Bus Configuration
Engine	Z16XER	Program Idle Speed
Engine	Z16XER	Reset ECU
Engine	Z16XER	Reset Learned Values
Engine	Z17DTH	Program High Speed CAN-Bus Configuration
Engine	Z17DTH	Replace Injector
Engine	Z17DTH	Replace Rail Pressure Sensor
Engine	Z17DTH	Reset ECU
Engine	Z18XE	ECU Control
Engine	Z18XE	Program High Speed CAN-Bus Configuration
Engine	Z18XE	Reset ECU
Engine	Z18XER	ECU Control

Engine	Z18XER	Program High Can
Engine	Z18XER	Program High Speed CAN-Bus Configuration
Engine	Z18XER	Program Idle Speed
Engine	Z18XER	Reset ECU
Engine	Z18XER	Reset Learned Values
Engine	Z19DT	Program High Speed CAN-Bus Configuration
Engine	Z19DT	Program Idle Speed
Engine	Z19DT	Program Injector
Engine	Z19DT	Regeneration Diesel Particulate Filter
Engine	Z19DT	Replace O2 Sensor
Engine	Z19DT	Replace Diesel Particulate Filter
Engine	Z19DT	Replace Injector
Engine	Z19DT	Replace Mass air flow sensor
Engine	Z19DT	Replace Precatalyst
Engine	Z19DT	Replace Rail
Engine	Z19DT	Reset ECU
Engine	Z19DT	Reset Engine Oil Life
Engine	Z19DTH	Program High Speed CAN-Bus Configuration
Engine	Z19DTH	Program Idle Speed
Engine	Z19DTH	Program Injector
Engine	Z19DTH	Regeneration Diesel Particulate Filter
Engine	Z19DTH	Replace O2 Sensor
Engine	Z19DTH	Replace Diesel Particulate Filter
Engine	Z19DTH	Replace Injector
Engine	Z19DTH	Replace Mass air flow sensor
Engine	Z19DTH	Replace Precatalyst
Engine	Z19DTH	Replace Rail Pressure
Engine	Z19DTH	Reset ECU
Engine Control Module	A13DTE	APP Learn
Engine Control Module	A13DTE	Catalyst Reset
Engine Control Module	A13DTE	Clutch Pedal Position Learn
Engine Control Module	A13DTE	Crankshaft Position Reluctor Wheel Learn
Engine Control Module	A13DTE	DPF Pressure Sensor Learn
Engine Control Module	A13DTE	DPF Reset
Engine Control Module	A13DTE	EGR Valve Learn
Engine Control Module	A13DTE	Engine Oil Life Reset
Engine Control Module	A13DTE	Exhaust Gas Temperature Sensor Learn
Engine Control Module	A13DTE	Flywheel Learn
Engine Control Module	A13DTE	Fuel Rail Pressure Sensor or Fuel Rail Learn
Engine Control Module	A13DTE	Glow Plug Control Module
Engine Control Module	A13DTE	H02S Learn
Engine Control Module	A13DTE	MAF Sensor Learn
Engine Control Module	A13DTE	Regeneration Diesel Particulate Filter
Engine Control Module	A16XER	Clutch Pedal Position Learn
Engine Control Module	A16XER	Crankshaft Position Variation
Engine Control Module	A16XER	Engine Oil Life Reset
Engine Control Module	A16XER	Fuel Trim Reset
Engine Control Module	A16XER	H02S Heater Learn
Engine Control Module	A16XER	Idle Learn
Engine Control Module	A18XER	Clutch Pedal Position Learn
Engine Control Module	A18XER	Crankshaft Position Variation
Engine Control Module	A18XER	Engine Oil Life Reset
Engine Control Module	A18XER	Fuel Trim Reset
Engine Control Module	A18XER	H02S Heater Learn
Engine Control Module	A18XER	Idle Learn
Engine Control Module	A20DTH	APP Learn
Engine Control Module	A20DTH	Catalyst Reset

Engine Control Module	A20DTH	Clutch Pedal Position Learn
Engine Control Module	A20DTH	Crankshaft Position Reluctor Wheel Learn
Engine Control Module	A20DTH	DPF Pressure Sensor Learn
Engine Control Module	A20DTH	DPF Reset
Engine Control Module	A20DTH	EGR Valve Learn
Engine Control Module	A20DTH	Engine Oil Life Reset
Engine Control Module	A20DTH	Exhaust Gas Temperature Sensor Learn
Engine Control Module	A20DTH	Flywheel Learn
Engine Control Module	A20DTH	Fuel Rail Pressure Sensor or Fuel Rail Learn
Engine Control Module	A20DTH	Glow Plug Control Module
Engine Control Module	A20DTH	H02S Learn
Engine Control Module	A20DTH	MAF Sensor Learn
Engine Control Module	A20DTH	Regeneration DPF
Engine Control Module	A20DTH	Regeneration Diesel Particulate Filter
Engine Control Module	A20DTJ	APP Learn
Engine Control Module	A20DTJ	Catalyst Reset
Engine Control Module	A20DTJ	Clutch Pedal Position Learn
Engine Control Module	A20DTJ	Crankshaft Position Reluctor Wheel Learn
Engine Control Module	A20DTJ	DPF Pressure Sensor Learn
Engine Control Module	A20DTJ	DPF Reset
Engine Control Module	A20DTJ	EGR Valve Learn
Engine Control Module	A20DTJ	Engine Oil Life Reset
Engine Control Module	A20DTJ	Exhaust Gas Temperature Sensor Learn
Engine Control Module	A20DTJ	Flywheel Learn
Engine Control Module	A20DTJ	Fuel Rail Pressure Sensor or Fuel Rail Learn
Engine Control Module	A20DTJ	H02S Learn
Engine Control Module	A20DTJ	MAF Sensor Learn
Engine Control Module	A20DTJ	Regeneration DPF
Fuel Pump Control Module	FPCM	Fuel Trim Reset
Instrument Cluster	IC	CAN Bus Configuration Learn
Parking Brake Control Module	PBCM	Park Brake Calibration
Remote Heater and Air Conditioning Control Module	RHACCM	CAN Bus Configuration Learn
Remote Heater and Air Conditioning Control Module	RHACCM	HVAC Actuators Learn
Transmission Control Module	TCM	Gear Selector N Position Learn
Transmission Control Module	TCM	Learned Values Reset